HD33 and HD3300 Discrete IR Codes

Optoma Code : 32CD

Key	Description	Key code
1	Power ON key	02
2	Brightness key	41
3	Power OFF key	2E
4	Contrast key	42
5	Gamma key	43
6	Lamp Mode key	45
7	Menu key	0E
8	Remote mouse emulation ↵ key	0F
9	Remote mouse emulation Left key	10
10	Remote mouse emulation Up key	11
11	Remote mouse emulation Right key	12
12	Remote mouse emulation Down key	14
13	Mode key	05
14	16:9 key	46
15	4:3 key	47
16	LBX key	48
17	Native key	49
18	PureEngine key	4A
19		4B
20	HDMI1 key	16
21	HDMI2 key	30
22	YPbPr key	17
23	VGA key	1B
24	Video key	1C