## **Example connector**





# Front (plug)

Rear (crimp plug)

### **STEP A:**

Take the connector rear



This connector

The crimp terminal "hollow" side should be up

### **STEP B:**

Insert crimp Until the "click" sound is heard



#### **STEP C:**

Repeat steps A and B for all wires

