
## Home / Study Guide Comments

1 SEGGER SYSVIEW P1 1.1 Overview and termir 1.2 Using SEGGER\_SY 1.2.1 Supported forma 1.2.2 Omitted error-ch 1.3 Bugs in SEGGER S 1.3.1 The User-Guide 1.3.2 "%%" causes bu 1.3.3 "%c" with 0x00 1.3.4 "%s" use incorre 2 SystemView Recorder: r 2.1 Timestamps in the th 2.2 The Terminal windo 2.3 Events List window 2.4 Timeline window 3 Upgrading SystemView 3.1 Upgrading the files i 3.2 Upgrading instances 4 SystemView troubleshoo 4.1 SystemView problen

4.2 SystemView problen

4.3 SystemView problen 4.4 SystemView bug: do 4.5 Console output for a




## 2.1 Timestamps in the three windows

- Where timestamps are displayed:
  - o The "Events List" and Terminal windows, in a column
  - o The Timeline window: at the "marker". The marker is the blue vertical line
- There are three types of timestamp formats:
  - o "Target time" and "recording time" formats can be selected via the "View" menu:



- The "reference" time-format is selected via the "R" key. It is described in the SystemView *User Guide*.
- The timestamp-formats used in each window
  - The Events List and Terminal windows always use the same timestamp format (whichever one has been selected in the "View" menu)
  - The Timeline window's timestamp-format is always "recording time".
- "Recording time" is relative to the first recorded event, which occurs at time 0. An example is below.
  - o Events List window:



• "Target time" is presumably relative to a timer on the board. The first event typically occurs at a time greater than 0, e.g., "16:46.579 973 167". An example is below. It shows the same windows as above, but using the "target time" format.

o Events List window: