

Model: FJZ ADB SKU: 9630000073



Description of Issue:

Air Conditioner not turning on.

230VAC Power confirmed to be supplied to the RTU (Roof Top Unit)

ADB (Air Distribution Box) display PCB not turning on.

Method: Visually check that the communication loom with 4 pin plug from the RTU is plugged into the ADB display PCB “COMU” socket and not into the “CAN” socket at the other end of the ADB display PCB.



Correct end
has **COMU**
and only one
loom for the
light.

Incorrect end
has **CAN** and
3 other looms
for light,
ionizer and
thermistor.