

T500 Mosfet Upgrade

I do not recommend doing this unless your warranty has expired

Prerequisites

Hardware:

Amazon 30a Mosfet <https://www.amazon.com/gp/product/B08YZ4W4LN>

or

Big Red <https://www.amazon.com/gp/product/B074KZF772>)

STL Files:

1x Mosfet Adapter <https://www.thingiverse.com/thing:6375709>

Mosfet Install

- Follow this video to remove your mosfet
<https://fb.watch/oX4d6himoZ/>
- Take the 4 screws from the mosfet and install the Mosfet adapter you printed above
- Take 2 or 4 Screws and install your mosfet to the adapter plate
- Plug the 2 wire control into the board
- Install the 2 wires that come from the PS into the POWER of the New Board (See Diagrams Below)
- Plug to 2 Wires from the Bed Heater into the HOT BED connections (See Diagrams Below)

- Power on your Machine and TEST

