


# طراحی سیستمهای ریزپردازنده

رابطهای سریال SPI و 12C

دانشکده مهندسی برق دانشگاه صنعتی شاهرود

حسين خسروي

14..



## Serial Peripheral Interface (SPI) Bus

- ◄ هیچ مشخصات رسمی برای رابط SPl وجود ندارد
- ▶ مراجعه به برگه مشخصات قطعه مورد استفاده ضروری است
  - مناسب برای برای اتصال مدارهای مجتمع روی بُرد
- ◄ پارامترهای مهم: فرکانس های کاری مجاز و نوع انتقال معتبر
  - پیکربندی پایه پیرو (یک یا چند پیرو)
  - پایه (فرمانده) معمولا یک ریزپردازنده است

# سایر ویژگیهای رابط SPI

- ▼ تولید کنندگان متعددی این رابط را در قطعات خود استفاده می کنند (ابتدا موتورولا)
  - ◄ محصولات سازندگان مختلف به طور مستقیم با هم سازگار نیستند!
- ◄ لیکن معمولا با تغییرات کوچک در پارامترها، امکان هماهنگی هست


- ◄ برخی قطعاتی که از SPI استفاده می کنند:
- Flash EEPROM, ADC, DAC, temperature sensor, digital IO,RTC digital potentiometer etc.

## سیگنالهای SPI

- □ گذرگاه SPI شامل چهار سیگنال است:
- □ SCLK Serial Clock (output from master)
- MOSI Master Output, Slave Input (output from master)
- MISO Master Input, Slave Output (output from slave)
- □ SS Slave Select (active low; output from master)
  - No Slave Addressing
    - □ سایر نامهایی که برای این سیگنالها استفاده می شود:
- □ SCK, CLK Serial Clock (output from master)
- □ SDI, DI, SI Serial Data In
- □ SDO, DO, SO Serial Data Out
- □ SSEL Slave Select

## **Typical SPI Configuration**


- ◄ فرمانده سیگنال Slave Select را صفر می کند و سپس پالسهای ساعت را ایجاد می کند
  - فرکانس ساعت در این پروتکل مشخص نشده است و بسته به
     ویژگی های دستگاه پیرو، می تواند از ۱ تا ۷۰ مگاهرتز باشد
    - ◄ سپس انتقال داده انجام می شود
    - در نهایت فرمانده، ییرو را از حالت انتخاب خارج می کند



### Simple master slave implementation

- During each SPI clock cycle, a full duplex data transmission occurs:
  - ☐ the master sends a bit on the MOSI line; the slave reads it from that same line
  - ☐ the slave sends a bit on the MISO line; the master reads it from that same line
- Not all transmissions require all four of these operations to be *meaningful* but they do happen.
- The number of bits transferred is not fixed but is usually a multiple of 8-bits.

#### **Basic serial data transfer**



The registers within the master and slave act like shift registers shifting one bit on every cycle of the SCLK.


### **Data transfer details**

- Most SPI interfaces have two configuration bits, called clock polarity (CPOL) and clock phase (CPHA).
- CPOL determines whether the shift clock's idle state is low (CPOL=0) or high (CPOL=1).
- CPHA determines on which clock edges data is shifted in and out (for CPHA=0, MOSI data is shifted out on falling edge, MISO data is shifted in on rising edge).
- For two SPI devices to talk to each other, they need to be set to use the same clock polarity and phase settings.

#### **SPI Data Transfer Modes**


Mode	CPOL	СРНА	Active edge
0	0	0	Rising
1	0	1	Falling
2	1	0	Falling
3	1	1	Rising

- •Modes 0 and 3 are the most common.
- ■With SPI modes 0 and 3, data is always latched in on the rising edge of SCK and always output on the falling edge of SCK.



### **Multiple Slaves**

If multiple slave devices exist, the master normally generates a separate slave select signal for each slave.




#### **SPI Bus characteristics**

- It is up to the master and slave devices to know whether a received byte is meaningful or not.
- No Acknowledgement
- Master doesn't even know if slave is present!
- Slaves can be thought of as IO devices of the master.

### **Example SPI devices**

- 25LC020A 2K SPI Bus Serial EEPROM
- TC77-5.0 Thermal Sensor with SPI Interface
- MCP3201 2.7V 12-Bit A/D Converter with SPI Serial Interface
- MCP4822 12-Bit DAC with Internal VREF and SPI Interface
- MCP41010 Single/Dual Digital Potentiometer with SPI Interface
- MCP6S92 Single-Ended, Rail-to-Rail I/O, Low-Gain PGA

# 12C or TWI




### Introduction

- Serial communication protocol
- Meant for short distances "inside the box"
- Low complexity
- Low cost
- Low speed ( a few Mbps at the fastest )
- To be discussed: Applications, protocols, tradeoffs, AVR support

### What is I<sup>2</sup>C?


- Shorthand for an "Inter-integrated circuit" bus
- Developed by Philips Semiconductor for TV sets in the 1980's
- I<sup>2</sup>C devices include EEPROMs, thermal sensors, and realtime clocks
- I<sup>2</sup>C bus has three speeds:
  - Slow (under 100 Kbps)
  - ☐ Fast (400 Kbps)
  - $\square$  High-speed (3.4 Mbps)  $I^2C$  v.2.0
- Limited to about 10 feet for moderate speeds

## I<sup>2</sup>C Bus Configuration




- ☐ 2-wire serial bus Serial data (SDA) and Serial clock (SCL)
- Half-duplex, synchronous, multi-master bus
- No chip select or arbitration logic required
- Lines pulled high via resistors, pulled down via opendrain drivers

### I<sup>2</sup>C Protocol




- 1. Master sends start condition (S) and controls the clock signal
- 2. Master sends a unique 7-bit slave device address
- 3. Master sends read/write bit (R/W):
  - 0 slave receive,
  - 1 slave transmit
- 4. Receiver sends acknowledge bit (ACK)
- 5. Transmitter (slave or master) transmits 1 byte of data

## I<sup>2</sup>C Protocol (cont.)



- 6. Receiver issues an ACK bit for the byte received
- 7. Repeat 5 and 6 if more bytes need to be transmitted.
- 8.a) For write transaction (master transmitting), master issues stop condition (P) after last byte of data.
- 8.b) For read transaction (master receiving), master does not acknowledge final byte, just issues stop condition (P) to tell the slave the transmission is done

## I<sup>2</sup>C Signals



- Start high-to-low transition of the SDA line while SCL line is high
- Stop low-to-high transition of the SDA line while SCL line is high
- Ack receiver pulls SDA low while transmitter allows it to float high
- Data transition takes place while SCL is low, valid while SCL is high

#### I<sup>2</sup>C Features

- "Clock stretching" when the slave (receiver) needs more time to process a bit, it can pull SCL low. The master waits until the slave has released SCL before sending the next bit.
- "General call" broadcast addresses every device on the bus
- 10-bit extended addressing for new designs. 7-bit addresses all exhausted

### **AVR Support for I<sup>2</sup>C**

- Atmel calls it "Two-wire Serial Interface" (or TWI)
- Supported by all AVR 8-bit μC except ATTiny and AT90

#### ATmega323 TWI mode when TWEN in TWCR is set:

- PC0=SCL, PC1=SDA
- TWBR sets bit rate
- TWCR controls start, stop, ack generation, indicates M/S, T/R
- TWDR contains byte transmitted/received
- TWAR contains slave address
- TWSR indicates status of TWI Bus (start condition transmitted, ACK received, ... 26 total states)

### I<sup>2</sup>C Tradeoffs

#### Advantages:

- Good for communication with on-board devices that are accessed occasionally.
- Easy to link multiple devices because of addressing scheme
- Cost and complexity do not scale up with the number of devices

#### Disadvantages:

The complexity of supporting software components can be higher than that of competing schemes (for example, SPI).

# انواع دسترسی به رابط ۱2C در کدویژن

◄ برای دسترسی به رابط دو سیمه و استفاده از آن در AVR بوسیله نرم افزار کد ویژن به دو صورت میتوان عمل کرد:

■ دسترسی به واسط ۱2C با استفاده از واحد سخت افزاری TWI

◄ دسترسی به واسط 12C به صورت نرم افزاری با اضافه کردن فایل سرآیه i2c.h

### تفاوت های استفاده از واسط سخت افزاری و نرم افزاری

- در صورت استفاده از واسط سخت افزاری تنها میتوان پایه های SDA و SCL میکرو را استفاده نمود در حالی که در حالت نرم افزاری هر دو پایه دلخواه را می شود استفاده کرد.
- در حالت نرم افزاری، بخشی از پردازنده، درگیر تولید پالس های
   کلاک و ارسال داده می شود در حالی که در واسط سخت افزاری،
   یک واحد مجزا درگیر می شود و سرعت برنامه بیشتر است.
- در صورت استفاده از 2Cانرم افزاری، با اضافه شدن فایل سرآیهی مربوطه میتوان از توابع آماده موجود استفاده کرده اما در حالت سخت افزاری ظاهرا فایل سرآیهی آماده ای نیست و باید با ثباتها کار کنید!

# توابع در حالت نرم افزاری

- void i2c\_init(void)
- ▶ این تابع گذرگاه TWI نرم افزاری را روی مقادیرSDA و SCL اولیه فراخوانی و راه اندازی می کند. به همین دلیل باید قبل از فراخوانی توابع دیگر این تابع را صدا زد.
  - unsigned char i2c\_start(void) <
  - ◄ با اجرای این تابع یک وضعیت start ایجاد می شود و اگر گذرگاه 12C آزادباشد ، مقدار ۱ توسط این تابع باز می گردد وگرنه صفر بر می گردد
    - void i2c\_stop(void)
    - ◄ يک وضعيت توقف ايجاد مي کند
    - unsigned char <a href="i2c\_read">i2c\_read</a>(unsigned char ack)
  - ◄ یک بایت می خواند. اگر پارامتر ورودی صفر باشد، تقاضای acknowledgeبعد از خواندن، نمی کند وگرنه تقاضا می کند.

# توابع 12C نرم افزاری

- unsigned char i2c\_write(unsigned char data) <
- ◄ داده را روی باس می نویسد. خروجی ۱ است اگر گیرنده ack بدهد وگرنه صفر برمی گرداند.

## مثال نوشتن در EEPROM مدل AT24C08A 8k

## Two-wire Serial EEPROM

1K (128 x 8)

2K (256 x 8)

4K (512 x 8)


8K (1024 x 8)

16K (2048 x 8)

AT24C01A<sup>(1)</sup> AT24C02<sup>(2)</sup> AT24C04 AT24C08A AT24C16A<sup>(3)</sup>


 Table 1. Pin Configuration

Pin Name	Function	
A0 - A2	Address Inputs	
SDA	Serial Data	
SCL	Serial Clock Input	
WP	Write Protect	
NC	No Connect	
GND	Ground	
VCC	Power Supply	



## آدرس دهی قطعه


- سه پایه A0,A1,A2 آدرس قطعه را مشخص می کند که شرکت اتمل برای اینکه امکان استفاده از چندین حافظه EEPROM در یک گذرگاه آن را تعبیه کرده است. بنابراین تا ۸ آی سی حافظه را میتوان روی گذرگاه قرار داد.
  - LSB بیانگر خواندن یا نوشتن خواهد بود



# نوشتن

- برای نوشتن در این آی سی از پروتکل ۱2Cابه دو صورت خاص استفاده می شود. اولی برای نوشتن یک بایت در آن و دومی نوشتن یک صفحه که متشکل از چندین بایت پشت سر هم است
- در نوشتن به صورت بایتی ابتدا آدرس قطعه مشخص می شود، سپس
   آدرس خانه ای از حافظه که میخواهیم در آن بنویسیم مشخص می
   شود و در نهایت داده ی مورد نظر برای ذخیره ارسال می شود.


#### Byte Write



# نوشتن بلوکی از بایتها

▼ نوشتن صفحه ای همانند نوشتن بایتی است با این تفاوت که بعد از ارسال بایت اول، بایت های بعدی پشت سر هم ارسال میشوند و سپس سیگنال توقف ارسال خواهد شد.

Figure 9. Page Write



## **کد برای خواندن و نوشتن در AT24C08A 8k**

```
/* include the I2C bus functions
 The I2C bus connections and bit rate must be specified in the
 Project | Configure | C Compiler | Libraries | I2C menu */
#include <i2c.h>
/* function declaration for delay_ms */
#include <delay.h>
#define I2C 7BIT DEVICE ADDRESS 0x50 //1010 000*
کم ارزشترین بیت، بیانگر خواندن با نوشتن است//
#define EEPROM BUS ADDRESS (I2C 7BIT DEVICE ADDRESS << 1)
```

## كد خواندن

```
/*read a byte from the EEPROM */
unsigned char eeprom_read(unsigned int address)
   unsigned char data;
   i2c start();
   i2c_write(EEPROM_BUS_ADDRESS | 0); //0 means write →
   /*send MSB of address */
   i2c write(address >> 8);
   /*send LSB of address */
   i2c_write((unsigned char)address);
   i2c start();
   i2c_write(EEPROM_BUS_ADDRESS | 1); //1 means read →
   data = i2c read(0);
   i2c stop();
   return data;
```


## **کد برای نوشتن بایت**

```
/* write a byte to the EEPROM */
void eeprom_write(unsigned int address, unsigned char data)
{
   i2c_start();
   i2c write(EEPROM BUS ADDRESS | 0);
   /*send MSB of address */
   i2c write(address >> 8);
   /*send LSB of address */
   i2c_write((unsigned char)address);
   i2c write(data);
   i2c stop();
   /* 10ms delay to complete the write operation */
   delay_ms(10);
```

## برنامه تست

```
void main(void)
   unsigned char i;
   /* initialize the I2C bus */
   i2c init();
   /* write the byte 55h at address AAh */
   eeprom_write(0xaa, 0x55);
   /* read the byte from address AAh */
   i = eeprom_read(0xaa);
   while (1); /* loop forever */
```

### SPI vs. I<sup>2</sup>C



- □ For point-to-point, SPI is simple and efficient
  - Less overhead than I<sup>2</sup>C due to lack of addressing, plus SPI is full duplex.
- For multiple slaves, each slave needs separate slave select signal
  - More effort and more hardware than I<sup>2</sup>C

### **Summary**

- I<sup>2</sup>C and SPI provide good support for communication with slow peripheral devices that are accessed intermittently, mainly EEPROMs and real-time clocks
- I<sup>2</sup>C easily accommodates multiple devices on a single bus.
- SPI is faster, but gets complicated when there is more than one slave involved.