Welcome!

JSSAP_PASSIVE _RANGING

by NAVSEA

Step by Step

Instructions

Contents

IntroductionPa	ige# 1
ContentsPa	age# 2
PartsPa	age # 3
Parts AssemblyPa	age # 4
Wire Connection AssemblyPa	ige # 5
Wire Connection AssemblyPa	age # 6
Computer setup Pa	age # 7
System OperationPa	age # 8
System OperationPa	age # 9
System OperationPa	ge # 10

PARTS

Parts	QTY.
Motor mount assembly	1
Control Box	1
Focus Lens assembly Focus???	1
Zoom Lens assembly Zoom???	1
Camera	1
Blue USB cable xTYPExxxxx???	1
Black USB cable xTYPExxxxxx???	1
Gray USB cable xTYPExxxxxxx???	1
Control box Power cable	1
7/32 Hex bit	1
Screw to 7/32 hex	1
5/32 Hex bit	1
Screw to 5/32 hex	2
USB hub	1
Mounting Tripod	1
Strap????	1
Control motors ???	2
Pelican Case ???	1
Tripod Bag ???	1

Page 3 of 10

Parts Assembly

- 1. **Open** pelican case and remove top layer protective foam.
- Take lens assembly which it's compose of zoom lens, focus lens and camera.
 Place it on top of motor mount assembly. Camera will correspond with the direction of control box.
- Locate screw corresponding to 7/32 hex bit and screw-in lens assembly to motor mount assembly. The screw hole is located under motor mount assembly, secure tightly.
- 4. Locate **strap** on top of motor mount and **wrap** over lens. Once over the lens, take the strap and pass trough side bracket. While firmly pulling on the strap **secure** by tighten the **screws** on bracket with 5/32 hex bit.
- 5. Once everything its in place, **Zero the lens** assembly system. In the center of lens assembly locate the two gears attached to the lenses. If **standing in front** of lens assembly as an object, place hands on **gears** and softly **turn** them **clockwise** all the way until both gears won't move any further.
- 6. Ensure **small gears** attached to the two motors are **align** with the **bigger gears** attache to the lenses.
- 7. With the help of someone, take the **lens** assembly system and place it on mount. Example a **tripod**.
- 8. Well done! you have completed the part assembly portion.



Lorem ipsum dolor sit amet, ligula suspendisse nulla pretium.



Lorem ipsum dolor sit amet, ligula suspendisse nulla pretium.



Lorem ipsum dolor sit amet, ligula suspendisse nulla pretium.

Wire Connection Assembly

- Locate Blue USB cord and connect to camera, ensure cable is tightly screw in to camera.
- 2. Locate **Black USB** "mini" and connect to the control box.
- Locate power cable and connect to control box and plug in to wall outlet.
 Once power is apply and Led will blink "blue and green"
- 4. V1 Next is to connect the trigger. Locate gray usb cable with gray box. Connect the corresponding end of cable to the camera. Pull the mechanism at the end on the cable, insert and release in to camera jack.
- 5. V2 Locate gray USB cable and connect from camera to control box
- 6. Locate **blue USB** cable from camera and connect **to the computer.**
- 7. Locate **black USB** cable from control box and connect **to the computer.**
- 8. Locate **Gray USB** cable from camera and connect **to the computer.**
- 9. **If desire** connect all USB's to USB hub and connect USB hub to the computer.
- 10. Well done! you have completed the wire connection assembly portion.



Lorem ipsum dolor sit amet, ligula suspendisse nulla pretium.



Lorem ipsum dolor sit amet, ligula suspendisse nulla pretium.



Lorem ipsum dolor sit amet, ligula suspendisse nulla pretium.

Wire Connection Assembly

Computer Set up

liquam amet est, quam leo maecenas mauris turpis leo pharetra, vulputate lacus. Tortor vitae tortor eros wisi facilisis. Nisl rhoncus turpis est, elit, wisi enim nunc ultricies, magna tincidunt. Maecenas aliquam maecenas ligula, accumsan taciti. Sociis mauris in integer, a dolor netus non dui aliquet, sagittis felis sodales, dolor sociis mauris, vel eu libero cras. Faucibus at. Arcu habitasse elementum est, ipsum purus pede porttitor class, ut adipiscing, aliquet sed auctor, imperdiet arcu diam dapibus libero duis. Enim eros in vel, nec pellentesque leo, temporibus scelerisque nec.

Ac dolor ac adipiscing amet bibendum nullam, lacus molestie ut libero nec, diam et, pharetra sodales, feugiat ullamcorper tempor vitae. Mauris pretium aliquet, lectus tincidunt. Porttitor mollis imperdiet libero senectus pulvinar. Etiam molestie mauris ligula laoreet, vehicula.

Eleifend. Repellat orci erat et, sem cum, ultricies sollicitudin amet eleifend dolor nullam erat, malesuada est leo ac. Varius natoque turpis elementum est.

Duis montes, tellus lobortis lacus amet arcu et. In vitae vel, wisi at, praesent bibendum libero faucibus porta egestas, quisque praesent ipsum fermentum tempor. Curabitur auctor, mollis sed, turpis vivamus dictumst congue magnis. Aliquam amet ullamcorper dignissim molestie, mollis. Tortor vitae tortor eros wisi facilisis. Consectetuer ipsum ornare pellentesque vehicula, in vehicula diam, magna erat felis wisi a risus. Justo fermentum id. Malesuada eleifend, tortor molestie, vel et. At suspendisse, neque aliquam faucibus adipiscing, vivamus in. Wisi mattis leo suscipit nec amet, nisl fermentum tempor ac a, augue eleifend venenatis, cras sit id in vestibulum felis in, sed ligula. In sodales

Systems operation

Systems operation

Systems operation