Pulse Watch S - Getting Started Guide

The Pulse Watch S is a smartwatch with health tracking, notifications and 5 ATM water resistance. It works with Android 10+ and iOS 15+ through the NovaTech Health app.

Setup: charge the watch for 10 minutes, press and hold the side button to turn it on, then open the NovaTech Health app and tap 'Add device'. Keep the phone close to the watch.

Specifications: 1.43-inch AMOLED display, 42 g with strap, GPS, heart-rate and SpO2 sensors, Bluetooth 5.2, 5 ATM water resistance.

Battery and charging

Typical battery life is 7 days, or about 2 days with the always-on display enabled. Continuous GPS workouts last up to 18 hours.

Charge with the magnetic charging puck. A full charge takes about 90 minutes. Make sure the charging contacts are clean and dry before charging.

Water resistance

The Pulse Watch S is rated 5 ATM: suitable for swimming in a pool or shallow water. It is not suitable for diving, water skiing, saunas or hot showers.

Rinse the watch with fresh water after swimming in the sea and dry it before charging. Water damage caused by misuse is not covered by the warranty.

Health and fitness features

Heart rate is measured continuously; SpO2 can be measured on demand or overnight. Sleep tracking starts automatically when you wear the watch to bed.

Over 100 workout modes are available. Auto-detection recognizes walking, running and cycling after about 10 minutes of activity.

Health readings are for general wellness only and are not intended for medical diagnosis.

Troubleshooting

Screen flickers or turns on randomly: update to the latest firmware in the NovaTech Health app (Device > Firmware). If flickering continues after charging, restart the watch by holding the side button for 15 seconds. Persistent flicker should be inspected through an in-store repair appointment.

Watch not syncing: make sure Bluetooth is on and the NovaTech Health app is allowed to run in the background, then pull down to refresh in the app.

Factory reset: on the watch, go to Settings > System > Reset. This erases all data stored on the watch.