
```
% Richie Ngo, Johhny Zhu
% MIE 597G
% Lab #1: Analog Circuits
% Part 2.3
s = tf('s');
R1 = 4.7*10^3;
                % Ohms
R2 = 470*10^3;
                % Ohms
C1 = 1*10^-6;
                % Farads
C2 = .01*10^{-6}; % Farads
tau = R1*C1;
                % Time constant
G = R2*C1;
                % Gain
sys = -G*s/(tau*s+1)^2;
bode(sys);
```



Published with MATLAB® R2015b