ATP Level Test Bench USB to LabVIEW 4 Device Under Test (DUT) Capacity H-Bridge Controller 12Vdc @5A Fwd, Rev, Brake DO 5Vdc @100ma x3 How does 5Vdc Gnd this wire to H-Bridge Circuit 250Ω @0.01% the DUT? Digital I/O Channels 0-6 14 W x4 (x2) D0 Event Markers in WinDag D1 Remote Start/Stop in WinDag +5V Out D2 Can be used for Rate applications +5Vdc D3 Can be used as a Counter channel D6 Can be used as an External Sample Trigo To four Ch A Drive USB flash drive port for To four Ch B Remote Event push-button stand-alone data logging Trigger events either from the remot event inputs (through WINDAQ soft-To Ground ware) or by pushing this button. 00000000000000000 Bulkhead Mounting Ears **TB1** Model DI-2108 Button DATAQ 10 circuit USB to #10V # 5 100V M **LED** Indication See Specifications for LED status Analog input x8

Voltage Range: ±10 Volts; Up to ±50V without damage

16 bit +/-10Vdc +/-5mV