


The Keyboard

Hsi-Pin Ma

https://eeclass.nthu.edu.tw/course/18498
Department of Electrical Engineering
National Tsing Hua University



FPGA Configuration






USB-UART Bridge (Serial Port)

FTDI FT2232HQ

- Allow to use PC applications to communicate with the board using standard Windows COM port commands
 - Virtual Com Port convert USB packets to UART/serial port data
 - Serial port data is exchanged with the FPGA using a two-wire serial port (TXD/RXD)






USB HID Host

- USB HID (Human Interface Device) host capability
 - Aux function microcontroller (Microchip PIC24FJ128)
- PIC24FJ128 function
 - Power-up: configuration mode
 - After programmed: application mode (USB HID Host mode)

Do not support Hub. Only a single mouse or a single keyboard

can be used (standard PS/2 interface)








Peripheral A

USB HID Host






HID Controller

• 11-bit words protocol

start bit, data byte (LSB first), odd parity, stop bit




Symbol	Parameter	Min	Max
T _{CK}	Clock time	30us	50us
T_{SU}	Data-to-clock setup time	5us	25us
T _{HLD}	Clock-to-data hold time	5us	25us



4x4 Keypad

Keypad scan








PS/2-style Keyboard Operation

- Use *scan codes* to communicate key press data
 - Each key is assigned a code
 - If the key is held down, the scan code will be sent repeatedly about once every 100ms. (make code)
 - When a key is released, an F0 key-up code is sent, followed by the scan code of the released key. (break code)
 - Some keys (right Ctrl, right Alt, ...), called extended keys,
 send an E0 ahead of the scan code. (extend code)


Example PC compatible (IBM PS/2) scancodes



key	set 1 (IBM PC XT)		set 2 (IBM PC AT)		set 3 (IBM 3270 PC)	
Key	press	release	press	release	press	release
A (normal letter)	1E	9E	1C	F0 1C	1C	FØ 1C
Return / Enter (main keyboard)	1C	9C	5A	FØ 5A	5A	FØ 5A
Enter (numeric keypad)	E0 1C	EØ 9C	E0 5A	E0 F0 5A	79	FØ 79
Left Windows key	E0 5B	EØ DB	E0 1F	E0 F0 1F	8B	FØ 8B
Right Windows key	E0 5C	EØ DC	E0 27	E0 F0 27	8C	FØ 8C



PS/2 Keyboard Scan Code



We only use the yellow parts of the keyboard.

Extend Code	Break Code	Make code	
E0	F0	XX	

(means "release")

$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	E012E07C E11477E1F014F077 Prt Scr L Pause Brk
(a) (b) (c) (Ins Home P Up E070 E06C E07D T7 E04A TC TB
12	E075 69 72 7A Enter ← B06B E072 E074 70 71 E05A

L Alt press			11
L Alt release		F0	11
R Alt press	E0		11
R Alt release	E0	F0	11




PS/2-style Keyboard Operation

- A host device can also send data to the keyboard
- The keyboard can send data to the host only when both the data and clock lines are high (or idle)
 - If the host drive the clock line low, the keyboard must not send any data until the clock is released.
- The keyboard generates 11 clock transitions (at 20 to 30 KHz) when the data is sent, and data is *valid on the falling edge* of the clock.
- When a keyboard or a mouse is connected to the Basys3, a "self-test passed" command (0xAA) is sent to Basys3
- A Read ID command (0xF2) from Basys 3 is used to identify what kind of device is connected



KeyboardDecoder



Inout:

PS2_DATA, PS2_CLK rst (high active reset) clk (100MHz)

Outputs:

last_change [8:0]

extend code make code


key_down [511:0]: address of the key pressed

key_valid: high for 1 clock period (100MHz) when a key is pressed or released



KeyboardDecoder

FSM in the decoder





For Lab8

- Use KeyboardDecoder to get the codes of pressed key
- Remember to add three .v files into your projects
 - Ps2Interface.v
 - KeyboardCtrl.v
 - KeyboardDecoder.v