CHT + PARK BRAKE BOARD


Up to four Adafruit MCP9601 thermocouple amplifiers (5165), one per cylinder: each takes its Type K thermocouple in its own screw terminal. ADDR sets the address: socket 1 to GND 0x60, 2 by 22k 0x65, 3 by 43k 0x66, 4 open 0x67. ALERT1–4 not used. Parking brake: +12V via 2.2k (breakout board) –> D1 –> U1 LED –> J2 SW; the switch closes to GND when the brake is set: BRAKE (GPIO 9) low. Pins with the same label are joined.

CYL 1: I2C 0x60



CYL 1 MCP9601

CYL 2: I2C 0x65



CYL 2 MCP9601

CYL 3: I2C 0x66




CYL 3 MCP9601


CYL 4: I2C 0x67




CYL 4 MCP9601




AUX TO BREAKOUT J18



LED_green




PC817



PARK BRAKE



1N4148





H1–H4: M3 board mounting. H5–H12: M2.5, two per module, 11 mm standoffs.

Thermocouple amplifier carrier and parking brake input, on the breakout board AUX plug

Sheet: /
File: cht-board.kicad_sch

Title: M.O.S.S. CHT + Parking Brake Board – Bobcat M700

Size: A3	Date: 2026-10-24	**Rev: 1.0**
KiCad E.D.A. 10.0.7		Id: 1/1