

SOP — Corrosion and Thickness Monitoring

Document ID: APEL-SOP-INS-222 | Owner: Inspection & Integrity | Revision: 7.0

This page defines the task-specific controls for measurement planning.

Measurement planning

- Identify susceptible locations.
- Use consistent points.
- Review prior thickness maps.
- Add points after abnormal findings.

Measurement record

This page defines the task-specific controls for measurement record.

Measurement record

- Gauge ID
- Calibration date
- Location code
- Nominal thickness
- Measured thickness
- Inspector

Trend analysis

This page defines the task-specific controls for trend analysis.

Trend analysis

- Preserve location code.
- Distinguish depth from rate.
- Do not infer annual rate without comparable dated readings.

Review triggers

This page defines the task-specific controls for review triggers.

Review triggers

- P-102 depth above 3 mm
- Accelerating trend
- Unexpected pitting
- Active leakage evidence

Quality controls

This page defines the task-specific controls for quality controls.

Quality controls

- Record location changes.
- Use valid calibration.
- Retain raw measurements.