```
# BitCounter returns the number of bits that are equal 1 in an N-bit long bit vector.
# Assumes a big endian machine.
# For example, a 40-bit vector with bits 0, 9, 18, 27, 36 equal 1 is stored in memory:
# 1000 0000 0100 0000 0010 0000 0001 0000 0000 1000 xxxx xxxx xxxx xxxx xxxx xxxx
# Input Parameters:
   $a0: Memory address of the first position of the vector.
   1: unsigned integer that contains the number of bits in the bit vector (could be 0).
# Return Value:
# $v0: Number of bits that are one in the vector
# Algorithm:
# Pointer = MemoryAddress
# OneCount = 0
# BitCount = NumberOfBits
   while(BitCount > 0)
       word = *Pointer;
       for( mask = 0 \times 800000000; mask != 0 && BitCount > 0; mask = mask >> 1){
           temp = word & mask
#
           if(temp != 0)
             OneCount = OneCount + 1;
#
           BitCount = BitCount -1;
#
       Pointer++;
   return OneCount
# Register Usage:
   $a0: Pointer
   $a1: BitCount
   $t1: word
  $t2: mask
   $t5: temp
# $v0: OneCount
```

Figure 1: File Header for BitCounter

Question 3 (30 points): A common requirement in the implementation of static analysis for a compiler is the manipulation of bit vectors with arbitrary length. In this question you will write the assembly MIPS code for a subroutine, BitCounter, that receives two parameters:

\$a0: contains the memory address of the first byte that contains the bit vector

\$a1: contains an unsigned integer that specifies the length, expressed in bits, of the bit vector

BitCounter returns in \$v0 the number of bits in the bit vector that are equal 1.

In the interest of time, you are provided with the header for your assembly file, containing an algorithm specification and register usage, is provided in Figure 1.

```
BitCounter:
            $v0, $zero, $zero # OneCount <-- 0
    add
    ble
            $a1, $zero, Done
                               # if BitCount <= 0 goto Done
NextWord:
            $t1, 0($a0)
    LW
                               # word = *Pointer
            $t2, 0x8000
                               # mask = 0x8000 0000
    lui
NextBit:
            $a1, $zero, Done
                               # if BitCount ⇐ 0 goto Done
    ble
                              # temp <-- word & mask
            $t5, $t1, $t2
    and
    beq
            $t5, $zero, NotOne # if word & mask != 0 goto NotOne
    addi
            $v0, $v0, 1
                               # OneCount <-- OneCount + 1
NotOne:
            $t2, $t2, 1
    srl
                               # mask <-- mask>>1
            $a1, $a1, -1
                               # BitCount <-- BitCount - 1
    addi
    bne
            $t2, $zero, NextBit # if mask != 0 goto NextBit
    addi
            $a0, $a0, 4
                               # Pointer++
            $zero, $zero, NextWord
    beq
Done:
            $ra
    jr
```

Figure 2: MIPS Assembly Code for BitCounter