

Quillmere DW700 Dishwasher User Manual

1. Specifications and Cycles

- Capacity: 14 place settings.
- Noise level: 44 dBA.
- Normal cycle: 2 hours 10 minutes. Quick cycle: 60 minutes.
- Other cycles: Heavy and Eco. The upper rack height is adjustable.

2. Detergent, Rinse Aid, and Cleaning

White spots or a cloudy film on dishes are usually caused by hard water. Raise the rinse aid setting to 4 or 5 (the scale runs from 1 to 5) and refill the rinse aid dispenser.

Use detergent pods or powder made for automatic dishwashers. Clean the filter at the bottom of the tub once a month.

3. Error Codes

- E04: Heater fault. Schedule service.
- E11: Incoming water too hot. The inlet water temperature should be below 150 degrees F.
- E17: Water supply problem. Make sure the water supply valve is open.
- E21: Drain blocked. Clean the drain filter at the bottom of the tub and check the drain hose for kinks.