
## Chapter 12 Microcells

#### Microcells

- Smaller cells for increased capacity
- Reduce base station height
- Accurate path loss models needed


UNIK4150/9150

# Microcell: street canyon




UNIK4150/9150

## Dual-slope path loss model




Note Plane Earth model (Ch. 5.6):  $\Delta r \approx 2h_{\rm m}h_{\rm b}/r$ Let  $\Delta r = \lambda/2$ . Then  $r \approx 4h_{\rm m}h_{\rm b}/\lambda$  Street measurement example


- Routes A, B and C are radial, often line-ofsight
- Route D is transverse to path, mostly nonline-of-sight



#### Measurements at 900 MHz




## Line-of-sight physical model




Similar to Plane Earth model, but  $r_1$  and  $r_2$  not necessarily similar. R is the reflection coefficient.







# Street canyon geometry









## Effect of base station height evaluated at 100 m




## Street geometries



# Rooftop diffraction



## Non-LOS propagation mechanisms




**A**, **B** strong paths, dominated by diffraction or reflection

**C** involves multiple reflection so weak relative to roof-top diffracted **D** 

# Path loss contours

Greater path loss across streets (diffraction) compared to along streets (reflection)




#### Recursive model

Find illusory distance:

$$d_{j} = k_{j} \cdot r_{j-1} + d_{j-1}$$

$$k_{j} = k_{j-1} + d_{j-1} \cdot q(\theta_{j-1})$$

$$k_{0} = 1 \text{ and } d_{0} = 0$$



Distance increases with turning angle:

$$q(\theta_j) = \left(\frac{0.5\theta_j}{90}\right)^{1.5}$$

Then path loss has dual-slope behaviour:

$$L = 20 \log \left( \frac{4\pi d_n}{\lambda} D \left( \sum_{j=1}^n r_{j-1} \right) \right) \quad \text{where} \quad D(r) = \begin{cases} r/r_b & \text{for } r > r_b \\ 1 & \text{for } r \le r_b \end{cases}$$
$$r_b = 4h_b h_m / \lambda$$

UNIK4150/9150

15

## ITU-R P.1411 Non-line of sight model in street canyon

#### Method based on multiple knife-edge diffraction

#### **Parameters**

w1: street width (m) at base station (BS)

w2: street width (m) at mobile station (MS)

x1: distance (m) from BS to street crossing


x2: distance (m) from MS to street crossing

 $\alpha$ : angle (rad) of corner

$$L_{NLoS2} = -10\log(10^{-L_r/10} + 10^{-L_d/10})$$

where  $L_r$  is the reflection path loss and  $L_d$  the diffraction path loss

# FIGURE 3 Definition of parameters for the NLoS2 case




#### ITU-R P.411 NIoS2

$$L_{NLoS2} = -10\log(10^{-L_r/10} + 10^{-L_d/10})$$

$$L_r = 20 \log(x_1 + x_2) + x_1 x_2 \frac{f(\alpha)}{w_1 w_2} + 20 \log(\frac{4\pi}{\lambda})$$

where 
$$f(\alpha) = \frac{3.86}{\alpha^{3.5}}$$
 0.6 < \alpha < \pi


## FIGURE 3 Definition of parameters for the NLoS2 case



$$L_d = 10\log[x_1x_2(x_1 + x_2)] + 2D_a - 0.1\left(90 - \alpha \frac{180}{\pi}\right) + 20\log\left(\frac{4\pi}{\lambda}\right)$$


where 
$$D_a = \left(\frac{40}{2\pi}\right) \left[\arctan\left(\frac{x_2}{w_2}\right) + \arctan\left(\frac{x_1}{w_1}\right) - \frac{\pi}{2}\right]$$

## Site specific ray model



UNIK4150/9150

## Narrowband Rician fading



UNIK4150/9150

#### Wideband effects

- Reduced delay spread
- Typical RMS delay spread about 0.5 μs
- Of interest as wideband applications are becoming more important

## ITU-R P.1411 microcell delay spread model

Delay spread follow normal distribution with mean  $a_s$  and standard deviation  $\sigma_s$ , given with parameters from the table. Developed for 2.5-15.75 GHz and 50 to 400 m distances.

$$a_s = C_a d^{\gamma_a}$$
$$\sigma_s = C_{\sigma} d^{\gamma_{\sigma}}$$

$$\sigma_{s} = C_{\sigma} d^{\gamma_{\sigma}}$$

Measurement conditions					a <sub>s</sub>		S <sub>s</sub>	
Area	f (GHz)	<i>h<sub>b</sub></i> (m)	<i>h<sub>m</sub></i> (m)	C <sub>a</sub>	γ <sub>a</sub>	<b>C</b> <sub>s</sub>	$\gamma_{s}$	
Urban	2.5	6.0	3.0	55	0.27	12	0.32	
	3.35-15.75	4.0	2.7	23	0.26	5.5	0.35	
			1.6	10	0.51	6.1	0.39	
	3.35-8.45		0.5					
	8.05	5	2.5	0.97	0.78	1.42	0.52	
Residential	3.35	4.0	2.7	2.1	0.53	0.54	0.77	
	3.35-15.75		1.6	5.9	0.32	2.0	0.48	

UNIK4150/9150 21

## Microcells summary


- Microcells essential for high capacity systems
- Clutter has major effect on cell coverage and interference
- Empirical models require dual slope behaviour
- Physical models attractive (but more complex)
- Antenna patterns often destroyed by clutter

## Chapter 13 Picocells

#### Picocells

- Base station inside buildings
- High telephone density areas (shopping centres etc)
- High data rate applications (WLAN)
- In building propagation relevant to macro/micro penetration

## **Picocells**



#### Pico cell models

- Significantly affected by environment geometry
- Simple path loss models inadequate
- Must account for wall and floor penetration

## Empirical methods for indoor propagation

- Based on measured data
- Characterised by distance, perhaps frequency and then walls and floors penetrated
- Fixed wall or floor attenuation only partly dependent on frequency and type of material

#### Wall and floor factor models


Other empirical methods needed for indoor propagation.

Free space loss (dB) plus attenuation term for each wall and floor intersected by direct path between transmitter and receiver

$$L = L_1 + 20 \log r + n_f a_f + n_w a_w$$

where *n* is number and *a* attenuation factors of floors (f) or walls (w)

## Example wall factor prediction



#### ITU-R model

- Loss per floor dependent on number of floors
- Walls not explicitly accounted for; instead path loss exponent dependent on environment and frequency

$$L_{\rm T} = 20\log f_{\rm c} + 10n\log r + L_{\rm f}(n_{\rm f}) - 28$$


#### Path loss exponent, n

Frequency	Environment					
(GHz)	Residential	Office	Commercial			
0.9	-	3.3	2.0			
1.2-1.3	-	3.2	2.2			
1.8-2.0	2.8	3.0	2.2			
4.0	-	2.8	2.2			
60	-	2.0	1.7			


#### Floor penetration factor, $L_{\rm f}(n_{\rm f})$

Freq.	Environment				
(GHz)	Res.	Office	Comm.		
0.9	1	9 (1 floor)			
		19 (2 floors)	-		
		24 (3 floors)			
1.8-2.0	4 <i>n</i> <sub>f</sub>	15+4( <i>n</i> <sub>f</sub> -1)	$6+3(n_{\rm f}-1)$		





### Ericsson model



## Propagation method for wireless local area network

Empirical method for Wi-Fi (2.4 GHz or 5.2 GHz)

$$L_{\rm T} = 19.7 + 37.3 \log f + 18.3 \log r + n_{\rm w} [21 \sin \theta + 12.2(1 - \sin \theta)] + 8.6 n_{\rm f}$$

where  $\theta$  is the wave incidence angle to the wall

- Obtained in a frequency range 0.9-5.7 GHz and assumed valid for office environments
- Such a model is fitted to measurement data and will need a large number of measurements for various environments.
   May change with new or other measurements


## Physical based indoor propagation methods

Ray tracing, here ray i

$$E_{i} = E_{0} f_{ti} f_{ri} L_{FSL}(r) \left[ \prod_{j} \overline{R}_{j} \prod_{k} \overline{T}_{k} \prod_{l} \overline{D}_{l} A_{l}(S_{l}, S_{l}') \right] e^{-jkr}$$

where E is the electric field,  $f_{ti}$ ,  $f_{ri}$  the transmit and receive antenna gains,  $L_{FSL}$  the free space loss, R the reflection coefficient, T the transmission coefficient, D the diffractions coefficient and A the spreading attenuation, and  $e^{-jkr}$  the phase factor

## Physical indoor propagation model




For Path 0 
$$P_r \propto \frac{P_T}{r_0^2 \gamma^n}$$

For Path 0  $P_r \propto \frac{P_T}{r_0^2 \gamma^n}$  where  $\gamma$  is attenuation per floor and n number of floors

UNIK4150/9150 34


#### Diffraction

Using GTD for paths 1,2 and 3:




$$P_{r} = P_{t} \left(\frac{\lambda}{4\pi}\right)^{2} \frac{D_{1}^{2} D_{2}^{2}}{r_{1} r_{2} r_{3} (r_{1} + r_{2} + r_{3})}$$


## Path loss versus number of floors



# COST 231 line-of-sight model

For penetration into buildings with line-of-sight to external wall





$$L_{T} = L_{F} + L_{e} + L_{g} (1 - \cos \theta)^{2} + \max(L_{1}, L_{2})$$

where  $L_{\rm e}$  is external wall loss,  $L_{\rm g}$  additional wall loss, and  $L_{\rm 1}, L_{\rm 2}$  loss within buildings

$$L_1 = n_W L_i$$
  $L_2 = \alpha (r_1 - 2)(1 - \cos \theta)^2$ 

UNIK4150/9150


## COST 231 loss model parameters

- Valid for distances up 500 m
- 900 1800 MHz

Parameter	Material	Approximate value
$L_{\rm e}$ or $L_{\rm i}$ (dB/m)	Wooden wall	4
	Concrete with non-metallised windows	7
	Concrete without windows	10-20
L <sub>g</sub> (dB)	Unspecified	20
lpha (dB/m)	Unspecified	0.6

# Floor gain referred to street level

- For non-line-of-sight incidence
- Internal loss related to external loss at street level:  $L_p = L_f(n) L_{out}$



## Floor gain model parameters

Frequency [MHz]	Ground Floor Penetration Loss $Lf(0)$ [dB]
900	14.2
1800	13.4
2300	12.8

- Loss decreases with height at around 2dB per floor up to some threshold floor (9-15), probably depending on height of surrounding buildings
- Subsequently increases with height

#### COST 231 Non-LOS model


$$L_T = L_{out} + L_e + L_{ge} + \max(L_1, L_3) - G_{jh}$$

where  $L_3 = \alpha r_i$  and  $r_i$ ,  $L_e$ , and  $L_1$  are as in the LOS model, and  $G_{jh} = nG_n$  or  $G_{jh} = hG_h$ 

Parameter	Approximate value	
L <sub>ge</sub> at 900 MHz	4 dB	
L <sub>ge</sub> at 1800 MHz	6 dB	
G <sub>n</sub> at 900 or 1800 MHz	1.5-2 dB normal buildings	
	4-7 dB floor heights above 4m	

## Propagation mechanisms building penetration

Complicated, but with information about the dielectric material and geometry some calculations can be done. Example double-glazed window and transmission line theory. In addition a window is an aperture and the Fresnel zone size for penetrating through the window comes into account.



# Constitutive parameters of building material


#### Complex permittivity of some materials

	1 GHz	57.5 GHz	95.9 GHz
Concrete	7 - j0.85	7.0 - j0.43	6.2 - j0.34
Glass	7 - j0.1	6.81 - j0.17	

#### Constitutive parameters of some materials

	Frequency range	Permittivity	Conductivity
Brick	1.7 – 18 GHz	4.62 - 4.11	0.0174 - 0.0364
Concrete	3 – 24 GHz	5 - 7	0.0138 - 0.025
Wood	20 Hz – 100 GHz	1.2 - 6.8	0.005 - 0.063
Glass	VHF - microwave	4 - 9	0.00005 - 0.035

### Transmission loss through a window



Window in brick wall. Size  $0.8 \text{ m}^2$ . Single 8 mm glass,  $\varepsilon = 0.4$  and loss tangent = 0.0012. Transmitter and receiver 30 m and 2 m from window centre, respectively.

## Multipath effects


- Doppler spectrum of individual taps may be assumed uniform due to 3D angle-of-arrival distribution
- Note that f<sub>m</sub> may arise from moving scatterers as well as moving terminals

$$S(f) = \begin{cases} \frac{1}{2f_m} & |f| \le f_m \\ 0 & f > f_m \end{cases}$$

# Indoor office wideband channel parameters at 2 GHz, ETSI

Median channel $\tau_{rms} = 35 \text{ ns}$		Bad channel $\tau_{\rm rms} = 100~{\rm ns}$	
Rel. delay (ns)	Rel. power (dB)	Rel. delay (ns)	Rel. power (dB)
0	0	0	0
50	-3	100	-3.6
110	-10	200	-7.2
170	-18	300	-10.8
290	-26	500	-18
310	-32	700	-25.2

# Indoor double exponential power-delay profiles



## Ultra wide band (UWB) indoor propagation


- UWB much larger bandwidth transmitted than required for the information, practical systems occupies as much as 7.5 GHz.
   Can be used for very high data rates over short distances
- The power spectral density is small and interference to other systems negligible
- Simple theory,  $\gamma$  (dB/m) attenuation coefficient, for the received power  $P_r(r)$  and the power delay profile  $P(\tau)$

$$\frac{P_r(r)}{P_t} = \frac{1}{4\pi r^2} e^{\frac{-r^{\gamma}}{10}} \qquad P(\tau) = \frac{1}{\tau_{RMS}} e^{\frac{-\tau}{\tau_{RMS}}}$$

UNIK4150/9150

48

# Propagation in tunnels, main features



## Picocells summary

- In- building coverage biggest growth area
- Must incorporate effects of geometry for accurate path loss prediction
- Reasonable estimates available from simple models
- Wideband effects essential for high data rate applications