Instructions for The Puck

- 1) Remove your belt hook apparatus, including the pedestal (and the extra riser if you have a Railboard) with a Phillips head screwdriver. After removing the original belt hook screws, you may wish to clean the holes gently with a cotton swab, toothpick, etc.
- 2) The three barrel-head screws (2 large and 1 short) are for securing the Puck on the instrument, using the largest and smallest hex wrenches. After initially inserting the screws and making a few turns, gradually tighten them a bit at a time, going from screw to screw. If you screw in either side all the way from the beginning before any tightening of the other side, the Puck may tilt too much to be able to add the other screw(s). Make sure the Puck is secure, but be careful not to overtighten the screws.

Once the Puck is attached to the Stick, you can attach it to an NS stand via the center hole on the Puck.

