





Put C1 and C2 at the CC1101 VCC and GND pins.

ANT: 315 MHz antenna, or a 23.8 cm wire on modules with a solder pad.

Power from pin 17 (3.3 V), never pin 2 or 4 (5 V). Check the pin order against your module's silkscreen.

Enable SPI: dtparam=spi=on in /boot/firmware/config.txt. CSN uses CE0 (/dev/spidev0.0).

GDO0 and GDO2 are spare inputs, wired for listening to the real remote later.





Any 40-pin Pi. Pin numbers are physical. Not yet built. No Pi software yet.

rileyschuit/Proflame2-Remote

Sheet: /

File: rpi_cc1101.kicad_sch

Title: Raspberry Pi GPIO + CC1101 fireplace remote

Size: A4	Date:	**Rev: 0.1**
KiCad E.D.A. 9.0.8		Id: 1/1