# Prática 6

$I^2C$

**Inter-Integrated Circuit**

# $I^2C$

I2C is a serial, synchronous, half-duplex communication protocol that allows co-existence of multiple masters and slaves on the same bus. The $I^2C$ bus consists of two lines: serial data line (SDA) and serial clock (SCL). Both lines require pull-up resistors.

With such advantages as simplicity and low manufacturing cost, I2C is mostly used for communication of low-speed peripheral devices over short distances (within one foot).

ESP32 has 2 $I^2C$ controller (also referred to as port), responsible for handling communications on the $I^2C$ bus. A single I2C controller can operate as master or slave.

# $I^2C$


VDD
MASTER
Rp
Rp
SDA
SCL
SLAVE #1
SLAVE #2
SLAVE #3


Start Condition
Stop Condition
SDA
SCL


Start Condition
Asserted By Master
Asserted By Slave
SDA
ACK/NACK Bit
SCL
7-Bit Address
READ/WRITE Bit

# I²C - Write


VDD
Rp
Rp
MASTER
SDA
SCL
SLAVE #1
SLAVE #2
SLAVE #3


ACK/NACK Bit
Data Stays Stable During HIGH SCL Pulse
ACK/NACK Bit
Start Condition
7-Bit Address
READ/WRITE Bit
DATA BYTE
Stop Condition
SDA
1 1 0 0 1 0 0 0 A D7 D6 D5 D4 D3 D2 D1 D0 A
SCL
Data Transmitter
MASTER
SLAVE
MASTER
SLAVE
MASTER

# I²C - Read


VDD
Rp
Rp
MASTER
SDA
SCL
SLAVE #1
SLAVE #2
SLAVE #3


ACK/NACK Bit
ACK/NACK Bit
ACK/NACK Bit
Start Condition
7-Bit Address
READ/WRITE Bit
DATA BYTE
DATA BYTE
Stop Condition
SDA
1 1 0 0 1 0 0 1 A D7 D6 D5 D4 D3 D2 D1 D0 A D7 D6 D5 D4 D3 D2 D1 D0 NA
SCL
Data Transmitter
MASTER
SLAVE
MASTER
SLAVE
MASTER

# LCD

- Initialize I2C bus
- Install panel IO
- Install SSD1306 panel driver
- Initialize LVGL

# Initialize I2C bus

```
ESP_LOGI(TAG, "Initialize I2C bus");
    i2c_master_bus_handle_t i2c_bus = NULL;
    i2c_master_bus_config_t bus_config = {
        .clk_source = I2C_CLK_SRC_DEFAULT,
        .glitch_ignore_cnt = 7,
        .i2c_port = I2C_BUS_PORT,
        .sda_io_num = EXAMPLE_PIN_NUM_SDA,
        .scl_io_num = EXAMPLE_PIN_NUM_SCL,
        .flags.enable_internal_pullup = true,
    };
    ESP_ERROR_CHECK(i2c_new_master_bus(&bus_config, &i2c_bus));
```

# Install panel IO

```
ESP_LOGI(TAG, "Install panel IO");
    esp_lcd_panel_io_handle_t io_handle = NULL;
    esp_lcd_panel_io_i2c_config_t io_config = {
        .dev_addr = EXAMPLE_I2C_HW_ADDR,
        .scl_speed_hz = EXAMPLE_LCD_PIXEL_CLOCK_HZ,
        .control_phase_bytes = 1,               // According to SSD1306 datasheet
        .lcd_cmd_bits = EXAMPLE_LCD_CMD_BITS,   // According to SSD1306 datasheet
        .lcd_param_bits = EXAMPLE_LCD_CMD_BITS, // According to SSD1306 datasheet
        .dc_bit_offset = 6,                     // According to SSD1306 datasheet
    };
    ESP_ERROR_CHECK(esp_lcd_new_panel_io_i2c(i2c_bus, &io_config, &io_handle));
```

# Install SSD1306 panel driver

```
ESP_LOGI(TAG, "Install SSD1306 panel driver");
    esp_lcd_panel_handle_t panel_handle = NULL;
    esp_lcd_panel_dev_config_t panel_config = {
        .bits_per_pixel = 1,
        .reset_gpio_num = EXAMPLE_PIN_NUM_RST,
    };
    esp_lcd_panel_ssd1306_config_t ssd1306_config = {
        .height = EXAMPLE_LCD_V_RES,
    };
    panel_config.vendor_config = &ssd1306_config;
    ESP_ERROR_CHECK(esp_lcd_new_panel_ssd1306(io_handle, &panel_config, &panel_handle));
    ESP_ERROR_CHECK(esp_lcd_panel_reset(panel_handle));
    ESP_ERROR_CHECK(esp_lcd_panel_init(panel_handle));
    ESP_ERROR_CHECK(esp_lcd_panel_disp_on_off(panel_handle, true));
```

# Initialize LVGL

```
ESP_LOGI(TAG, "Initialize LVGL");
    const lvgl_port_cfg_t lvgl_cfg = ESP_LVGL_PORT_INIT_CONFIG();     lvgl_port_init(&lvgl_cfg);
    const lvgl_port_display_cfg_t disp_cfg = {
        .io_handle = io_handle,       .panel_handle = panel_handle,
        .buffer_size = EXAMPLE_LCD_H_RES * EXAMPLE_LCD_V_RES,
        .double_buffer = true,
        .hres = EXAMPLE_LCD_H_RES,       .vres = EXAMPLE_LCD_V_RES,
        .monochrome = true,
        .rotation = {
            .swap_xy = false,
            .mirror_x = false,
            .mirror_y = false,
        }
    };
    lv_disp_t *disp = lvgl_port_add_disp(&disp_cfg);
```

# Utilizando LVGL

```
lv_obj_t *scr = lv_disp_get_scr_act(disp);
lv_obj_t *label = lv_label_create(scr);
lv_label_set_long_mode(label, LV_LABEL_LONG_SCROLL_CIRCULAR);
lv_label_set_text(label, "Hello Espressif, Hello LVGL.");
lv_obj_set_width(label, disp->driver->hor_res);
lv_obj_align(label, LV_ALIGN_TOP_MID, 0, 0);
```

// Pode-se criar quantos labels forem necessários.

# https://components.espressif.com/



# LVGL - https://lvgl.io/



# Referências


- https://www.espressif.com/sites/default/files/documentation/esp32_technical_reference_manual_en.pdf