

BASE PLATE MAY BE BOLTED THROUGH FIBERGLASS WITHOUT BUSHINGS AT HIGH DENSITY FOAM CORE LOCATIONS

BASE PLATE SHOWN FOR ENTIRE LENGTH OF TOE-KICK FEATURE. ALTERNATELY CONSIDER ONLY PLACING FLANGES AT HANDRAIL POST/HIGH DENSITY FOAM CORE LOCATIONS FOLLOWING BUILD PRACTICALITY.

BASE PLATE FOR FORWARD-FACING WINDOWS -- SIZING TBD

HIGH DENSITY FOAM CORE (IN HULL LAMINATE)

BASE PLATE (BOLTED TO FIBERGLASS HULLS)

POSTS, STANCHIONS, OTHER HARDWARE (WELDED TO BASE PLATE OR SEPARATE FLANGE)

JIG FRAME LOCATIONS

