# Prekidi kod Arduina Internet stvari 2023. - II termin



### Nenad Petrović

Univerzitet u Nišu, Elektronski fakultet

<u>nenad.petrovic@elfak.ni.ac.rs</u>, kancelarija 323



## Uvod

- Prekid (engl. interrupt) koristimo u situacijama kada osluškujemo da li je došlo do određenog događaja u spoljašnjoj sredini, pri čemu želimo da mikrokontroler oslobodimo sa ciljem da obavlja neki drugi zadatak, bez propuštanja unosa, umesto da se blokira i vrti u beskonačnoj petlji dok vrši prozivku
- Bilo da je u pitanju pritisak tastera, zvučni senzor koji treba da registruje klik ili infracrveni senzor koji detektuje ubacivanje novčića u automat, upotrebom prekida se izbegava konstanta prozivka u programu (bez da se obavlja neki drugi, koristan zadatak), što rezultuje boljim iskorišćenjem (ograničene) procesorske moći, ali i pojednostavljenjem glavnog programa
- U Arduino programskom jeziku, od ključnog značaja za upotrebu prekida je funkcija attachInterrupt()
- Različiti digitalni pinovi kao izvori prekida, zavisno od Arduino modela

# Pregled pinova za prekide po modelima

DIGITALNI PINOVI ZA PREKIDE
2, 3
Svi digitalin pinovi
2, 3, 18, 19, 20, 21 (pinovi 20 i 21 nisu dostupni za upotrebu u okviru prekida dok se koriste za I2C komunikaciju)
0, 1, 2, 3, 7
Svi digitalni, osim 4
0, 1, 4, 5, 6, 7, 8, 9, A1, A2
2, 3, 9, 10, 11, 13, A1, A5, A7
Svi pinovi
Svi digitalin pinovi
Svi digitalni pinovi (Samo pinovi 2, 5, 7, 8, 10, 11, 12, 13 rade u režimu CHANGE)

## Parametri attachInterrupt

#### Varijante poziva

- attachInterrupt(digitalPinToInterrupt(pin), ISR, mode) (preporučeno)
- o attachInterrupt (interrupt, ISR, mode) (ne propručuje se)
- o attachInterrupt(pin, ISR, mode) (samo SAMD ploče, Uno WiFi Rev2, Due, i 101)

#### interrupt (int)

- o Broj interapta, ne slaže se nužno sa brojem pina
- Preporučljivo da se korsiti digitalPinToInterrupt(pin) da bi se na osnovu pina pribavio odgovarajući broj interapta na koji se zapravo mapira

#### pin

o Broj pina na Arduino ploči

#### ISR

- Uslužna prekidna rutina koja se poziva kada dođe do interapta
- Predstavlja funkciju bez parametara i ne vraća ništa

#### Mode

- o Definiše kada dolazi do okidanja prekida
- Postoje 5 mogućih vrednosti
  - LOW
    - Aktivira se prekid kada pin ima vrednost 0
  - CHANGE
    - Kada god se vrednost pina promeni
  - RISING
    - o Kada god pin promeni vrednost od 0 na 1
  - FALLING
    - o Kada ide od 1 na 0
  - HIGH
    - o Samo za Due, Zero i MKR1000 ploče
    - Uvek kada pin ima vrednost 1

# Rutine za opsluživanje prekida Interrupt Service Routines (ISR)

- Poseban tip funkcija koje imaju pojedina ograničenja
- Ne smeju da imaju parametre, niti da vraćaju nešto
- Generalno, gleda se da budu što kraće i brže
- Ako sketch koristi više ISR
  - o Samo jedna u istom trenutku
  - Drugi prekidi se izvršavaju po završetku prethodnog, zavisno od prioriteta
- Obično se preko globalnih promenljivih prenose podaci između ISR i glavnog programa

# Izvori prekida i ISR rutine Šablon

```
ISR (SOURCE vect)
```

INT0 vect INT1\_vect INT2 vect INT3\_vect INT6\_vect PCINT0\_vect TIMER1 CAPT vect TIMER1\_COMPA\_vect TIMER1 COMPB vect TIMER1 COMPC vect TIMER1 OVF vect TIMER0\_COMPA\_vect TIMER0 COMPB vect TIMERO OVF vect SPI\_STC\_vect USART1 RX vect USART1 UDRE vect USART1\_TX\_vect ANALOG COMP vect ADC vect EE READY\_vect TIMER3 CAPT vect TIMER3 COMPA vect TIMER3\_COMPB\_vect TIMER3\_COMPC\_vect TIMER3 OVF vect TWI\_vect SPM READY vect TIMER4\_COMPA\_vect TIMER4 COMPB vect TIMER4 COMPD vect TIMER4\_OVF\_vect TIMER4\_FPF\_vect

External Interrupt Request 0 External Interrupt Request 1 External Interrupt Request 2 External Interrupt Request 3 External Interrupt Request 6 Pin Change Interrupt Request 0 (from PCINT0 through PCINT7) Timer/Counter1 Capture Event Timer/Counter1 Compare Match A Timer/Counter1 Compare Match B Timer/Counter1 Compare Match C Timer/Counter1 Overflow Timer/Counter0 Compare Match A Timer/Counter0 Compare Match B Timer/Counter0 Overflow SPI Serial Transfer Complete USART1, Rx Complete **USART1** Data register Empty USART1, Tx Complete **Analog Comparator ADC Conversion Complete EEPROM Ready** Timer/Counter3 Capture Event Timer/Counter3 Compare Match A Timer/Counter3 Compare Match B Timer/Counter3 Compare Match C Timer/Counter3 Overflow 2-wire Serial Interface Store Program Memory Read Timer/Counter4 Compare Match A Timer/Counter4 Compare Match B Timer/Counter4 Compare Match D Timer/Counter4 Overflow Timer/Counter4 Fault Protection Interrupt

## Napomene o prekidnim rutinama


- sei()/cli()
  - o Globalno omogućiti / onemogućiti prekide
- delay() ne radi
  - o I sam koristi prekide
- micros() radi najviše 1-2ms
- milis() se ne povećava
- delayMicroseconds()se ponaša normalno
  - o Ne koristi nikakve brojače i prekide
- Serijski podaci koji se primaju dok se opslužuje prekid mogu biti izgubljeni
- Volatile mora da stoji za sve one globalne promenljive koje menjamo unutar tela ISR

### Primer 2

Implementirati Arduino program koji promenom vrednosti nekog od pinova pali i glasi LED

diodu prozivkom

```
const byte ledPin = 13;
const byte buttonPin = 19;
byte buttonValue;
void setup() {
 pinMode(ledPin, OUTPUT);
 pinMode(buttonPin, INPUT);
void loop() {
 buttonValue = digitalRead(buttonPin);
 if (buttonValue == LOW) {
     digitalWrite(ledPin, LOW);
 else if (buttonValue == HIGH) {
     digitalWrite(ledPin, HIGH);
```




# Pojam pull-up i pull-down otpornika

- Stanje visoke impedanse
  - Kada ulazni pin koji koristimo nije podešen na HIGH ili LOW, njegovo stanje "pluta"
  - Izbegavamo ovo stanje, dovodi potencijalno do nepredvidivosti u radu
- Kao rešenje pull-up i pull-down otpornici
  - Ovo nisu posebne vrste otpornika
  - Omogućavaju da zadržimo željeno stanje logičkog kola, bez obzira na uslove
  - Arduino pin je vezan preko ovog otpornika na konstantnu vrednost
    - +5V napajanje: pull-up
    - GND (masa): pull-down

## Nastavak: Pull-up i pull-down otpornici


- "Pull-up"
  - Levo na slici, omogućava držanje digitalnog ulaza (pina) na visokom naponskom nivou – HIGH
  - Vcc predstavlja izvor napajannja od 5V koji odgovara HIGH
  - Vout je izvod koji povezujemo na pin Arduina konfigurisanog kao ulazni
  - Sve dok ne pritisnemo taster \$1, pin Arduina će biti HIGH
  - Kada pritisnemo pin se povezuje sa masom i postavlja na niski naponski nivo LOW
  - Zbog osobine držanja HIGH stanja na pinu se zove pull-up
- "Pull-down"
  - Prikazan desno, služi održavanje LOW vrednosti
  - Povezan na masu (tačku nultog potencihala)
  - Onog trenutka kada bude pritisnut \$1, pin se povezuje sa izvorom napjanja Vcc i dovodi na stanje HIGH



### Primer 2b

- Implementirati Arduino program koji promenom vrednosti nekog od pinova pali i glasi LED diodu prozivkom – taster aktivan na 0
  - o Pull-up otpornik

```
const byte ledPin = 13;
const byte buttonPin = 19;
byte buttonValue;
byte state = LOW;
void setup() {
  pinMode(ledPin, OUTPUT);
  pinMode(buttonPin, INPUT);
void loop() {
  buttonValue = digitalRead(buttonPin);
  if (buttonValue == HIGH) {
     state=LOW;
     digitalWrite(ledPin, LOW);
  else if (buttonValue == LOW) {
     state=HIGH;
     digitalWrite(ledPin, HIGH);
```



### Primer 3

Implementirati Arduino program koji promenom vrednosti nekog od pinova koji je izvor

prekida pali i glasi LED diodu.

```
const byte ledPin = 13;
const byte interruptPin = 19;
volatile byte state = LOW;

void setup() {
   pinMode(ledPin, OUTPUT);
   pinMode(interruptPin, INPUT);
   attachInterrupt(digitalPinToInterrupt(interruptPin), blink, CHANGE);
}

void loop() {
}

void blink() {
   state = !state;
   digitalWrite(ledPin, state);
}
```

