




MAINTENANCE WORK INSTRUCTIONS

MAW154

Clean out filters on electrical panels

Rev: 0.0

Date 30/01/2009

No.	INSTRUCTIONS	KEY POINTS / CONTACTS
1.	Check out all humidifier filters.	  
2.	Remove filter by lifting it up and out. If the filter is dirty, cut out new filters from material roll kept in the stores.	 
3.	Lock out the filter and blow out any dust from components, Use a dusk mask.	 

Controlled
By:

QA DEPT

Approved By:

Signature:

Signature:

Date:

Page 1 of 1