

### Guia de Instalação do Quartus Prime Lite Edition

20.1.1.720



## Quartus Prime Lite Edition 20.1.1.720





<u>Instalação</u>



<u>Instalação</u>



<u>Instalação</u>



<u>Instalação</u>





## Download :: Quartus Prime Lite Edition (Free) 19.1.0.670 - Windows

https://fpgasoftware.intel.com/?edition=lite



PRODUCTS

SUPPORT

SOLUTIONS

DEVELOPERS

PARTNERS



USA (ENGLISH)



FPGA Software Download Center >

# Intel® Quartus® Prime Lite Edition Design Software Version 19.1 for Windows ID Date Version 664527 3/31/2019 19.1 \$ A newer version of this software is available, which includes functional and security updates. Customers should click here to update to the latest version.

Users should upgrade to the latest version of the Intel® Quartus® Prime Design Software. The selected version does not include the latest functional and security updates. If you must use this version of software, follow the technical recommendations to help improve security. For critical support requests, please contact our support team.

The Intel® Quartus® Prime Lite Edition Design Software, Version 19.3 is subject to removal from the web when support for all devices in this release are available in a newer version, or all devices supported by this version are obsolete. If you would like to receive customer notifications by e-mail, please subscribe to our subscribe to our customer notification mailing list.

To use the Intel® Quartus® Prime Lite Edition Design Software, Version 19.1 on Windows, you must download and install the patch available in this KDB Solution.

OS Support and IP support have changed in this release. Refer to the Release Notes for details.

Critical Issues and Patches for the Intel® Quartus® Prime Lite Edition Software, Version 19.1. Knowledge Base: Search for Errata. Also see Critical Issues and Patches. Problems and Answers on specific IP or Products.





## Download :: Quartus Prime Lite Edition (Free) 19.1.0.670 - Windows

#### Downloads

Multiple Download

**Individual Files** 

Additional Software

**Copyleft Licensed Source** 

#### Multiple Download

Intel® Quartus® Prime Lite Edition Software (Device support included)

Download

Quartus-lite-19.1.0.670-windows.tar

Size: 5.6 GB

SHA1: d81296437b5212c8a26d694342a8af0fee6c094a

#### What's Included?

- \*\* Nios® II EDS on Windows requires Ubuntu 18.04 LTS on Windows Subsystem for Linux (WSL), which requires a manual installation.
- \*\* Nios® II EDS requires you to install an Eclipse IDE manually.

#### Download and install instructions:

- 1. Download the software .tar file and the appropriate device support files.
- 2. Extract the files into the same temporary directory.
- 3. Run the setup.bat file.

Read Intel® FPGA Software Installation FAQ

Note: The Intel® Quartus® Prime software is a full-featured EDA product. Depending on your download speed, download times may be lengthy.





## Download :: Quartus Prime Lite Edition (Free) 19.1.0.670 - Windows

Prosseguir a instalação com as mesmas opções do Quartus Prime Lite Edition (Free) 20.1.1.720 - Windows 10.

Executar o software em modo de compatibilidade no Windows 11.



Pedro Miguens Matutino / Sérgio André

## Quartus Prime Lite Edition 20.1.1.720















<u>Instalação</u>





https://www.virtualbox.org


Em Mac OS devem instalar o software Virtual Box e depois criar uma máquina virtual Windows ou Linux, prosseguindo com a instalação respetiva.

(só funciona em Mac com processadores Intel)



## Download :: Quartus Prime Lite Edition (Free) 20.1.1.720 - Windows

https://fpgasoftware.intel.com/?edition=lite



Users should upgrade to the latest version of the Intel® Quartus® Prime Design Software. The selected version does not include the latest functional and security updates. If you must use this version of software, follow the technical recommendations to help improve security. For critical support requests, please contact our support team.

The Intel® Quartus® Prime Lite Edition Design Software, Version 20.1.1 is subject to removal from the web when support for all devices in this release are available in a newer version, or all devices supported by this version are obsolete. If you would like to receive customer notifications by e-mail, please subscribe to our subscribe to our customer notification mailing list.

Critical Issues and Patches for the Intel® Quartus® Prime Lite Edition Software, Version 20.1. Knowledge Base: Search for Errata. Also see Critical Issues and Patches.

Problems and Answers on specific IP or Products.



## Download :: Quartus Prime Lite Edition (Free) 20.1.1.720 - Windows

#### Downloads

Multiple Download

**Individual Files** 

Additional Software

**Copyleft Licensed Source** 

#### Multiple Download

Intel® Quartus® Prime Lite Edition Software (Device support included)

Download Quartus-lite-20.1.1.720-windows.tar

Size: 5.9 GB

SHA1: f1bec3a3bf03e7ab9106af5fac93475347b66e1e

#### What's Included?

- \*\* Nios® II EDS on Windows requires Ubuntu 18.04 LTS on Windows Subsystem for Linux (WSL), which requires a manual installation.
- \*\* Nios® II EDS requires you to install an Eclipse IDE manually.

#### Download and install instructions:

- 1. Download the software .tar file and the appropriate device support files.
- 2. Extract the files into the same temporary directory.
- 3. Run the setup.bat file.

Read Intel® FPGA Software Installation FAQ


Note: The Intel® Quartus® Prime software is a full-featured EDA product. Depending on your download speed, download times may be lengthy.












































## Download :: Quartus Prime Lite Edition (Free) 20.1.1.720 - Linux



https://fpgasoftware.intel.com/?edition=lite



Users should upgrade to the latest version of the Intel® Quartus® Prime Design Software. The selected version does not include the latest functional and security updates. If you must use this version of software, follow the technical recommendations to help improve security. For critical support requests, please contact our support team.

The Intel® Quartus® Prime Lite Edition Design Software, Version 20.1.1 is subject to removal from the web when support for all devices in this release are available in a newer version, or all devices supported by this version are obsolete. If you would like to receive customer notifications by e-mail, please subscribe to our subscribe to our customer notification mailing list.

Critical Issues and Patches for the Intel® Quartus® Prime Lite Edition Software, Version 20.1. Knowledge Base: Search for Errata. Also see Critical Issues and Patches. Problems and Answers on specific IP or Products.



#### Download :: Quartus Prime Lite

#### Downloads

Multiple Download

**Individual Files** 

Additional Software

**Copyleft Licensed Source** 

#### Multiple Download

Intel® Quartus® Prime Lite Edition Software (Device support included)

Download
Ouartus-lite-20.1.1.720-linux.tar

Size: 6.4 GB

SHA1: a7869d9813986f07987a7eb95177fe9c5061f521

#### What's Included?

\*\* Nios® II EDS requires you to install an Eclipse IDE manually.


#### Download and install instructions:

- 1. Download the software .tar file and the appropriate device support files.
- 2. Extract the files into the same temporary directory.
- 3. Run the setup.bat file.


Read Intel® FPGA Software Installation FAQ

Note: The Intel® Quartus® Prime software is a full-featured EDA product. Depending on your download speed, download times may be lengthy.

```
lsd@lsd-VirtualBox: ~/Quartus
 FI.
Lsd@lsd-VirtualBox:~$ cd Quartus/
lsd@lsd-VirtualBox:~/Quartus$ ./setup.sh
```









Installing Quartus Prime Lite Edition (Free) 20.1.1.720



#### Installation directory



Specify the directory where Quartus Prime Lite Edition (Free)	20.1.1.720 will be installed
Installation directory /home/lsd/intelFPGA_lite/20.1	
to to IID and to a	
InstallBuilder —	< Back Next > Cancel

Installing Quartus Prime Lite Edition (Free) 20.1.1.720



#### Select Components





Select the components you want to install							
Quartus Prime Lite Edition (Free)  Quartus Prime (includes Nios II EDS) (8800MB)  Quartus Prime Help (500.1MB)  Arria II (536.5MB)  Cyclone IV (516.3MB)  Cyclone 10 LP (293.5MB)  Cyclone V (1434.3MB)  MAX II/V (13.1MB)  MAX 10 FPGA (367.9MB)  ModelSim - Intel FPGA Starter Edition (Free) (5001  ModelSim - Intel FPGA Edition (5001.6MB)	You can add additional device support to an existing Quartus Prime software installation without having to reinstall the entire software package. Use the Install Devices command on the Tools menu in the Quartus Prime software to get started.  Select a component for more information						
	< Back Next > Cancel						

Installing Quartus Prime Lite Edition (Free) 20.1.1.720



#### Ready to Install



#### Summary:

Installation directory: /home/lsd/intelFPGA\_lite/20.1

Required disk space: 17465 MB Available disk space: 42746 MB

InstallBuilder — < Back Next > Cancel

Installing Quartus Prime Lite	e Editio	on (Free) 20.1	.1.720	- 🛚
Installing				(intel)
Wait while Setup installs Quartus Prime Lite Edition (Free	20.1.]	1.720		
InstallBuilder —				
		< Back	Next >	Cancel



