
2002D,2003D



Upd: 22 NOV 2005

030

2002D,2003D

REF	PART NO.	QTY			SEE SEC.	NOTES
1	834339	1	Starter motor			
	3803074	1	Starter motor, exch			Exchange unit
					030-1140	
2	959257	2				
3	940280	2	Spring washer			
4	943194	2				
5	955782	1				M8
6	872242	1	Relay			
7	861317	1				
8	965198	2				
9	946441	2				
10	945987	1	Lock washer			
11	855314	1				
12	946440	1				
13	860878	1	Current bar			
14		1	ALTERNATOR AND INSTALLATION COMPONENTS		030-0820	
15	840672	1				
16	941793	2				
17	824823	1				
18	955247	1	Screw			
19	955780	1				
20	876037	1				12V/30A
21	860143	1				
22	955119	4				
23	846648	Х				L = 3000 MM
	846649	Х				L = 5000 MM
	846650	Х				L = 7000 MM
24	872797	1	Instrument panel			
					030-1342	
25	863169	1				
26	858229	1				
27	947624	1				
28	846615	Х				
29	948210	Х				
30	860339	1	Relay			12V/50A
31	955138	1	Screw			
32	876586	1				
33	956075	2				
34	941905	2				
35	77796	1				50A
36	955138	2				
37	946834	1				
38		1	STUD, FLYWHEEL COVER			SEE GROUP 2A
39		1	_ ,			SEE GROUP 2A
40	070745	1				SEE GROUP 2A
41	872749	1				SEE GROUP 2A
42	0.40000	1				M5
43	940090		Washer			
44	673580	1				
45	861084	1		12.5		055 050115 51
46	18830	1		IK		SEE GROUP 2A
47	872772	1			000 1071	
		X	CABLES AND TERMINALS		030-1351	

7726000 - 030 - 030-0450 11363 Upd: 22 NOV 2005