
2003,2003B,D,2003AG,BG,2003SOLAS,2003B-SOLAS,2003T,2003TB,2003TB-SOLAS



Upd: 22 NOV 2005

## 2003,2003B,D,2003AG,BG,2003SOLAS,2003B-SOLAS,2003T,2003TB,2003TB-SOLAS

	D. 1. D. T. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1. 1.	<b>0</b> =1/	DECODIDE: 01		No==0
REF	PART NO.	QTY			NOTES
1	834337	1			
3	840274 840559	1			
4	925065	1	O-ring	IK	
5	840552	1	Gear, INNER	111	
6	840553	1			
7	840498	1			
8	6842273	1	Sealing ring	IK	(1306333)
9	967591	1	O-ring	IK	
10	955272	6	Screw		
11	949607		Spring washer		
12	1542265	1	Seat		
13	1542266	1	Sleeve		
14	471085	1			
15 16	840792 1542267	1	Spring Cover		
17	925065	1		IK	
18	955269		Screw	IN	
19	840846	1	Tube		
20	840318	1			STD
20	860150	1			2003,2003B. FOR ENGINES WITH REVERSE GEAR MS2B-L,INSTALLATION
	000.00		o a.poo		ANGLE 10 TO 15%Z9 WHEN OPERATING
					2003T,2003TB
21	949187	1			
22		1	OIL SUMP		*. INCLUDED IN ENGINE BLOCK.
23	840588	1	Strainer		INCLUDED IN ENGINE BLOCK.