
2003SOLAS,2003B-SOLAS



2003SOLAS,2003B-SOLAS

PART NO.	QTY	DESCRIPTION	NOTES
860082	1	Cylinder head	ALSO AVAILABLE AS AN EXCHANGE PART CONSISTING OF CYLINDER HEAD, INTAKE AND EXHAUST VALVES, VALVE SPRINGS, WASHERS AND LOCKS.
3803162	1	Cylinder head, exch	Exchange unit
	2	Valve guide	
		· O-ring	((000))
		Expansion plug	(192211)
		Distribution pipe Seeling ring	
858407			
859044		Gasket	
940142			
	3	Spacer sleeve	
	14	Stud	SEE GROUP 2C
			*
			*
			*
858369			
840831	1	Decal	
		Sealing ring	
			SEE GROUP 2B
			SEE GROUP 2B
	1	Gasket	
947624	1	Gasket	
	860082 3803162 840281 860267 945221 477024 840460 418445 966147 947630 858461 840210 858407 859044 940142 840441 840442 840900 859093 970888 924066 840590 940102 960138 858369	860082 1 3803162 1 840281 2 860267 3 945221 3 477024 7 840460 1 418445 1 966147 2 947630 2 858461 3 840210 14 858407 1 859044 1 940142 3 840441 3 840900 3 859093 1 970888 14 924066 3 840590 1 940102 1 960138 1 840831 1 418411 1 840740 1 955269 1 418445 1 840740 1 955269 1 858229 1	860082 1 Cylinder head 3803162 1 Cylinder head, exch 840281 2 · Valve guide 860267 3 · Spray sleeve 945221 3 · O-ring 477024 7 · Expansion plug 840460 1 · Distribution pipe 418445 1 · Sealing ring 966147 2 · Plug 947630 2 · Gasket 858461 3 · Valve seat 840210 14 Washer 858407 1 Valve cover 859044 1 Gasket 940142 3 Screw 840441 3 Spacer sleeve 840442 3 Rubber seal 840900 3 Washer 859093 1 Gasket 970888 14 Screw 940102 1 Screw 960138 1 Washer 858369 1