

Upd:2010-07-01

AQAD30A

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	846022	1	Injection pump	OLL OLO.	SPEC.NO.867715,867716,867718,867723,867830,867933,867934,
'	040022	'	Injection pump		867935.
2	1542171	1	Hub		OBSOLETE PART
3	947314	1	O-ring		
4	953046	3	Stud		
5	191172	3	Washer		
6	955782	3	Hexagon nut		
7	1542170	1	Fuel pump		
	273663	1	Repair kit		OBSOLETE PART
8	463392	1	Gasket		
9	941907	2	Spring washer		
10	955295	2	Hexagon screw		
11	840531	1	Fuel filter	18161	
12	846789	1	Bracket		FOR FRONTMOUNTED FUEL FILTER.
13	955301	2	Hexagon screw		SEE GROUP 2A
14	843075	1	Spacer sleeve		FOR FRONTMOUNTED FUEL FILTER.
	845589	1	Spacer sleeve		FOR FRONTMOUNTED FUEL FILTER.
15	955317	2	Hexagon screw		
16	960148	2	Washer		
17	846017	1	Fuel pipe		FOR FRONTMOUNTED FUEL FILTER.
18	947621	4	Gasket		
19	25167	2	Hollow screw		
20	11994	4	Gasket		
21	74040	1	Hollow screw		
22	846018	1	Fuel pipe		FOR FRONTMOUNTED FUEL FILTER.
23	845646	2	Fuel hose		
24	11994	2	Gasket		
25	74040	1	Hollow screw		
26	404279	2	Attaching clamp		FOR FRONTMOUNTED FUEL FILTER.
27	955272	1	Hexagon screw		FOR FRONTMOUNTED FUEL FILTER.
28	946035	1	Lock nut		FOR FRONTMOUNTED FUEL FILTER.
29	840105	2	Rubber sleeve		OBSOLETE PART
30	838583	1	Bracket		INCLUDED IN INSTALLATION KIT 838978.
31	955344	2	Hexagon screw		INCLUDED IN INSTALLATION KIT 838978.
32	843122	2	Spacer sleeve		INCLUDED IN INSTALLATION KIT 838978.
33	955317	2	Hexagon screw		
34	960148	2	Washer		
35	838587	1	Fuel pipe		INCLUDED IN INSTALLATION KIT 838978.
36	25167	2	Hollow screw		
37	947621	4	Gasket		
38	838586	1	Fuel pipe		INCLUDED IN INSTALLATION KIT 838978.
39	846780	1	Bracket		INCLUDED IN INSTALLATION KIT 838978.
40	955314	1	Hexagon screw		INCLUDED IN INSTALLATION KIT 838978.
41	952624	1	Clamp		INCLUDED IN INSTALLATION KIT 838978.
42	955892	1	Washer		INCLUDED IN INSTALLATION KIT 838978.
43	955271	1	Hexagon screw		INCLUDED IN INSTALLATION KIT 838978.
44	829146	1	Fitting		
45	954337	2	Nipple		
46	954323		Fitting nut		
47	11994	2	Gasket		
48	74040	1	Hollow screw		
49	845647	1	Return line		
50	844237	1	Hollow screw		INCLUDED IN FUEL INJECTION PUMP.
51	11994	2	Gasket		
52	74034	1	Hollow screw		
53	957171	9	Gasket		
54	1542155	4	Injector	18164	
	3803239	4	Injector, exch, exch	18164	
55	1542159	4	Washer		
56	1542158	4	Washer		
57	1542154	4	Heat shield		
58	1542157	4	Washer		
59	1542156	4	Yoke		OBSOLETE PART

7744050-23-18165D 7713 Upd:2010-07-01

AQAD30A

REP PART NO. AT DESCRIPTION SEE SEC. NOTES						
60 924068 4 Stud 61 1542197 4 Washer 62 955782 4 Hexagon nut 63 1544137 1 Leak-off line 64 74033 3 Hollow screw 65 1544151 1 Pressure pipe CYL.1, OBSOLETE PART 66 1544152 1 Pressure pipe CYL.2, OBSOLETE PART 67 1544153 1 Pressure pipe CYL.3 68 1544154 1 Pressure pipe CYL.4, OBSOLETE PART 69 470181 2 Clamp 70 470183 1 Clamp 71 941905 1 Spring washer	REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
61 1542197 4 Washer 62 955782 4 Hexagon nut 63 1544137 1 Leak-off line 64 74033 3 Hollow screw 65 1544151 1 Pressure pipe CYL.1, OBSOLETE PART 66 1544152 1 Pressure pipe CYL.2, OBSOLETE PART 67 1544153 1 Pressure pipe CYL.3 68 1544154 1 Pressure pipe CYL.4, OBSOLETE PART 69 470181 2 Clamp 70 470183 1 Clamp 71 941905 1 Spring washer	60	924068	4	Stud		
62 955782 4 Hexagon nut 63 1544137 1 Leak-off line 64 74033 3 Hollow screw 65 1544151 1 Pressure pipe CYL.1, OBSOLETE PART 66 1544152 1 Pressure pipe CYL.2, OBSOLETE PART 67 1544153 1 Pressure pipe CYL.3 68 1544154 1 Pressure pipe CYL.4, OBSOLETE PART 69 470181 2 Clamp 70 470183 1 Clamp 71 941905 1 Spring washer	61	1542197	4	Washer		
64 74033 3 Hollow screw 65 1544151 1 Pressure pipe CYL.1, OBSOLETE PART 66 1544152 1 Pressure pipe CYL.2, OBSOLETE PART 67 1544153 1 Pressure pipe CYL.3 68 1544154 1 Pressure pipe CYL.4, OBSOLETE PART 69 470181 2 Clamp 70 470183 1 Clamp 71 941905 1 Spring washer	62	955782	4	Hexagon nut		
64 74033 3 Hollow screw 65 1544151 1 Pressure pipe CYL.1, OBSOLETE PART 66 1544152 1 Pressure pipe CYL.2, OBSOLETE PART 67 1544153 1 Pressure pipe CYL.3 68 1544154 1 Pressure pipe CYL.4, OBSOLETE PART 69 470181 2 Clamp 70 470183 1 Clamp 71 941905 1 Spring washer	63	1544137	1	Leak-off line		
65 1544151 1 Pressure pipe CYL.1, OBSOLETE PART 66 1544152 1 Pressure pipe CYL.2, OBSOLETE PART 67 1544153 1 Pressure pipe CYL.3 68 1544154 1 Pressure pipe CYL.4, OBSOLETE PART 69 470181 2 Clamp 70 470183 1 Clamp 71 941905 1 Spring washer	64	74033	3	Hollow screw		
66 1544152 1 Pressure pipe CYL.2, OBSOLETE PART 67 1544153 1 Pressure pipe CYL.3 68 1544154 1 Pressure pipe CYL.4, OBSOLETE PART 69 470181 2 Clamp 70 470183 1 Clamp 71 941905 1 Spring washer	65	1544151	1	Pressure pipe		CYL.1, OBSOLETE PART
67 1544153 1 Pressure pipe CYL.3 68 1544154 1 Pressure pipe CYL.4, OBSOLETE PART 69 470181 2 Clamp 70 470183 1 Clamp 71 941905 1 Spring washer	66	1544152	1	Pressure pipe		CYL.2, OBSOLETE PART
68 1544154 1 Pressure pipe CYL.4, OBSOLETE PART 69 470181 2 Clamp 70 470183 1 Clamp 71 941905 1 Spring washer	67	1544153	1	Pressure pipe		CYL.3
70 470183 1 Clamp 71 941905 1 Spring washer	68	1544154	1	Pressure pipe		CYL.4, OBSOLETE PART
71 941905 1 Spring washer	69	470181	2	Clamp		
71 941905 1 Spring washer 72 955780 1 Hexagon nut	70	470183		Clamp		
72 955780 1 Hexagon nut	71	941905		Spring washer		
	72	955780	1	Hexagon nut		

7744050-23-18165D 7713 Upd:2010-07-01