
AD30A, AQAD30A, MD30A, TAMD30A, TMD30A



## AD30A, AQAD30A, MD30A, TAMD30A, TMD30A

REF	PART NO.	QTY	DESCRIPTION	SEE SEC.	NOTES
1	i AITINO.		ALTERNATOR	18231	NOILS
2	955293	1			
3	838987	1			
			• COMPONENTS		SEE GROUP 3
4	953067	3	Stud		
5	941908	3	Spring washer		
6	955783		Hexagon nut		
7	852986	1	Current bar		AQ
8	829714	1	Sealing ring		AQ
10	855314 941907	1	Nut Spring washer		AQ AQ
11	940199	1			AQ
12	855798	1	Protecting sleeve		AQ
13	853502	1	Fuse		AQ
14	853573	1	Nut		AQ
15	853572	1			AQ
16	941906	1	Spring washer		AQ
17	955781	1	Hexagon nut		AQ
18	838954	6	Glow plug		
19	1542296	1			OBSOLETE PART
20	941905	6	Spring washer		
21	955780	6	Hexagon nut		
22	1542408		Protecting casing		ODCOLETE DADT
23 24	838953 858078	1	Series resistance Bracket		OBSOLETE PART OBSOLETE PART
25	955268		Hexagon screw		UDSULETE PART
26	955268	1			
27	955296	1	Hexagon screw		
28	838955	1	Relay		
29	966689	1			
30	838955		Relay		
31	858058	1	•		
32	243572	1	O-ring		
33	843325	1	Temperature sensor		
34	822858	1			
35	957181	2			
36	858036	1		10007	SEE GROUP 3, OBSOLETE PART
37	843604		Instrument panel	18287	OBSOLETE PART
38 39	858057	1	Cable trunk		OBSOLETE PART
39		I	OIL PRESSURE SENDER		SEE GROUP 3
1					
1					
1					
1					
1					
1					

7744050-90-18230 7891 Upd:2010-07-01