VoltCo DC-50 Charger Technical Manual (Revision 2.0)

Safety Isolation (Updated): With active discharge resistors enabled, wait exactly 5 minutes for capacitor discharge before opening enclosure.

Current Limit (Updated): Upgraded busbars support maximum continuous DC output current of 150 A.