





CONFIGURATION NOTES FOR MULTIBAND ASSEMBLY

RNRAD1-COMBO Load Matrix

Hi Band

+ 1000MI- CONFIGURATION		Hi Band
* 1800MHz CONFIGURATION	Comp	RF3315
LOAD 0 OHM JUMPERS FOR R65, R76	L25	1.2nh
DO NOT LOAD R75, R78 (LOW BAND FILTER STEERING)	R72	DNL
DO NOT LOAD R64, R66, R67, R69 (PASSIVE ATTENUATION)	C88	12pf
F1 =	C113	1.8pf
	L32	0 ohms
	R73	DNL
* 1900MHz CONFIGURATION	L33	DNL
LOAD 0 OHM JUMPERS FOR R65, R76	L31	1.6nh
DO NOT LOAD R75, R78 (LOW BAND FILTER STEERING)	L28	82nh
DO NOT LOAD R64, R66, R67, R69 (PASSIVE ATTENUATION)	C115	0.5pf
F1 =	C134	1.5pf
	L29	DNL
	C87	DNL
	R61	0 ohms
* MULTIBAND CONFIGURATION	R63	DNL
LOAD 0 OHM JUMPERS FOR R65, R76	R62	0 ohms
DO NOT LOAD R75, R78 (LOW BAND FILTER STEERING)	U18	RF3315
DO NOT LOAD R64, R66, R67, R69 (PASSIVE ATTENUATION)	F2 - 1	1800
LOAD - RIGID COAX FOR JUMPER	F2 - 1	
LOAD - RIGID COAR FOR DUMEER		

THIS DESIGN IS PROVIDED UNDER THE TERMS OF THIS CREATIVE COMMONS PUBLIC LICENSE ("CCPL" OR "LICENSE"). THE WORK IS PROTECTED BY COPYRIGHT AND/OR OTHER APPLICABLE LAW. ANY USE OF THE WORK OTHER THAN AS AUTHORIZED UNDER THIS LICENSE OR COPYRIGHT LAW IS PROHIBITED. See http://creativecommons.org/licenses/by-saf3.0/[paglodd]

RN Radio RF - CONFIG NOTES COMBO HIBAND Document Number RNRAD1-HIBAND Rev 2 Wednesday, October 23, 2013 Sheet 4 of