



## Digital State-Feedback Tracking Systems

Goal: We want the sampled plant output  $y[k]$  to "track" a reference command signal  $r[k]$ . That is,  $y[k] \rightarrow r[k]$  (as  $k$  increases) (Assume a single-input, single-output system.)

Example: If  $r[k]$  is a step signal of height  $H$



Derivation: Start with a "design model" which is a cascade of the plant ZOH and an "additional dynamics" block:



Note:  $(\Phi_a, \Gamma_a)$  will be chosen later  
 $8 \times 8 \quad 8 \times 1$

The state vector of the design model is:

$$\underline{x}_d[k] = \begin{cases} \underline{x}[k] \\ \underline{x}_a[k] \end{cases} \begin{cases} \text{ } n \text{ variables} \\ \text{ } 8 \text{ variables} \end{cases}$$

From the diagram on the previous page

$$\underline{x}[k+1] = \underline{\Phi} \underline{x}[k] + \underline{f} u[k]$$

$$\underline{x}_a[k+1] = \underline{\Phi}_a \underline{x}_a[k] + \underline{f}_a c \underline{x}[k]$$

Thus, the state-space equation for the design model is

$$\begin{bmatrix} \underline{x}[k+1] \\ \underline{x}_a[k+1] \end{bmatrix} = \underbrace{\begin{bmatrix} \underline{\Phi} & 0 \\ \underline{f}_a c \underline{\Phi}_a & \underline{\Phi}_a \end{bmatrix}}_{\underline{X}_d[k+1]} \begin{bmatrix} \underline{x}[k] \\ \underline{x}_a[k] \end{bmatrix} + \underbrace{\begin{bmatrix} \underline{f} \\ 0 \end{bmatrix}}_{\underline{P}_d} u[k]$$

The design model is an  $(n+g)$ th-order system. Suppose we want to regulate the design model with digital state feedback.


The rule of thumb for choosing the sampling interval becomes:

$$T = \min \left( \frac{T_s}{2\alpha(n+g)}, \frac{\pi}{5\beta_{max}} \right)$$

$\Rightarrow s$  poles = ... choose  $n+g$  CL poles using the usual rules

$$\Rightarrow z$$
 poles =  $\exp(T * s$  poles)

$$\Rightarrow K_d = \text{place}(\underline{\Phi}_d, \underline{P}_d, z \text{ poles})$$



$$u[k] = -\underbrace{K_d}_{1 \times (n+g)} \underbrace{\underline{x}[k]}_{(n+g) \times 1}$$

Recall that  $\underline{x}_d(k) = \begin{bmatrix} \underline{x}(k) \\ \underline{x}_a(k) \end{bmatrix} \}_{n+g}$


Partition the feedback gain vector into two pieces:

$$K_d = \begin{bmatrix} K_1 & K_2 \end{bmatrix}_{1 \times (n+g)}^T \begin{matrix} \overbrace{1 \times n} \\ \overbrace{1 \times g} \end{matrix}$$

Then

$$u(k) = -K_d \underline{x}_d(k) = -K_1 \underline{x}(k) - K_2 \underline{x}_a(k)$$

Block diagram of the regulated design model:




This is a stable closed-loop system with  $n+g$  poles located at the numbers specified in  $\underline{\sigma}_{\text{poles}}$ .


The next step is to introduce a reference command signal  $r(k)$  into the above diagram. External signals added to a feedback loop do not change the closed-loop pole locations.

We also insert two minus signs in a way that does not change the feedback loop.

$$(-1) \cdot (-1) = 1$$



- Combine  $-K_2$  with  $-1$  to get  $K_2$
- "Push" the other minus sign back through the summing junction and change the signs on the two incoming signals.
- Combine  $K_2$  with  $(\Phi_a, \Gamma_a)$  to get a complete state-space block  $(\Phi_a, \Gamma_a, K_2)$
- Rotate the above diagram counter-clockwise to get  $r[k]$  on the left



Note: the poles of this CL system are still located at  $\pm j\omega_p$  (stable with a  $T_S$ -second settling time)

How to choose the additional dynamics for a SISO plant. [Easily generalizes to MIMO.]

We want to guarantee  $y[k] \rightarrow r[k]$  } error  
even with perturbations to the plant model.

Condition: to track  $r[k]$  with zero steady-state error, the matrix  $\Phi_a$  must have eigenvalues equal to the poles of the  $Z$  transform of  $r[k]$ .

If  $r[k]$  is a step of height  $H$ ,

$Z$  transform is  $\frac{H}{z-1} \leftarrow 1 \text{ pole at } z=1.$


So  $\Phi_a$  must have one eigenvalue equal to 1.

A  $1 \times 1$  matrix is its own eigenvalue, so choose  $\Phi_a = 1$  ( $g=1$ , additional dynamics use one state variable)

The second requirement is that  $(\Phi_a, \Gamma_a)$  is controllable, which implies that  $\Gamma_a$  be a nonzero number. Choose  $\Gamma_a = 1$ .

$(\Phi_a=1, \Gamma_a=1)$  is a digital integrator.

So the additional dynamics block is,



$$\begin{aligned} \dot{x} &= 0x + 1 \cdot u \\ A &= q, B = 1 \\ \Phi_a &= e^{A \cdot T} = e^0 = 1 \\ \text{so pole at } s=0 &\Rightarrow \text{pole at } z=1 \end{aligned}$$