
# Flooding Prepare for flooding emergencies:

 The captain or person in charge should demonstrate to all crewmembers where through hull lines and fittings are located, and how to operate valves in the event of unintentional flooding.





• Mark or label manifold pipes and valves.



• Install double clamps on rubber hose fittings.




## **Prepare for Flooding Emergencies**






Keep dogging devices greased and properly adjusted.





- Replace door gasket material when it becomes hardened or permanently grooved.
- Keep gaskets clean and paint free.




 Inspect watertight hatches to Ice Hold and Lazarette.

**Important:** Maintain watertight and weathertight integrity by closing watertight doors when operating at sea.



## **Prepare an Emergency Plugging Kit**



## Suggested items:

- •Wooden cone plugs (1x4, 2x8, 3 ½ x 8)
- ◆Wooden Wedges (rough cut)
- Duct tape
  Twine
  Oakum
  Plastic tie-wraps
  Bailing wire
  Screw Driver Set
- •Wrench set •Neoprene rubber (1 to 2sq. ft.)
- Flashlight and batteries
- •Extra rubber hoses and hose clamps



• Keep spare buckets with emergency kit.



## **Prepare Emergency Flooding Procedures**

- Immediately notify the captain or person-in-charge when flooding occurs.
- Sound the General Alarm.
- Close all watertight doors, hatches and air vents.
- Shut off electricity to the flooded area.
- Investigate the source of flooding by checking all valves, through-hull fittings and the ship's hull.
- Slow flooding rate by using materials such as rags, wooden plugs, wedges, rain gear, etc.
- Activate dewatering pumps to stay ahead of the water flow.
- Use bilge pumps, hand pumps and buckets to dewater the space.
- If conditions worsen, the captain will instruct personnel when to don life jackets or make preparations to abandon ship.
- Send Mayday.



## **Emergency Position Indicating Radio Beacons EPIRBs**







EPIRBs are electronic life saving devices designed to alert rescue authorities and help to indicate your location.

- Only Category I, Class 1, 406 MHz EPIRBs are permitted on commercial fishing vessels.
- · Category I EPIRBs deploy automatically.



- Designed to operate with satellites.
- Frequency 406 MHz is designated for distress only.
- EPIRB signal is fixed with your vessel's identity.
- Signal can be detected anywhere in the world. There is no range limitation.
- Signal accuracy from 1-1/4 to 3 miles.
- Beacons work best when floating in water.



#### **Certified EPIRBS**

EPIRBs must be certified by Coast Guard approved independent laboratories before they can be sold in the United States.



**COSPAS-SARSAT** is an international satellite search and rescue system established by the U.S., Canada, France and Russia to locate emergency radio beacons transmitting on the frequencies 121.5, 243 and 406 MHz.

#### **Testing EPIRBs**

- Test every month.
- Check battery expiration date.
- Check for cracks and water tightness. Moisture can activate the beacon.
- Check antenna for tightness and corrosion.

406 EPIRBs can be tested through its self-test function. Self-test will not generate a distress alert.

#### **Battery Replacement**

Batteries must be replaced by the date indicated on the EPIRB label.

 The battery must be replaced only by a certificated dealer approved by the manufacturer.



## **EPIRB Registration**

- NOAA-SARSAT EPIRB Registration is mandatory.
- There is no charge for this service.
- A valid decal affixed on the EPIRB is proof of registration.



- Registration is intended to save your life.
- Information will help confirm that a distress situation exists and arranges the appropriate rescue effort.
- Registration begins immediate action on the case.

**Important:** Unregistered distress alerts may take as much as 2 hours longer to reach the Coast Guard and have needlessly cost the lives of several fishermen.

Register with the **NOAA, SARSAT** Office, FB4, Room 3320, 5200 Auth Road, **Suitland**, **Maryland** 20746

Or online at:

www.beaconregistration.noaa.gov

It may save your life.

Warning! Activating a beacon for reasons other than to indicate a distress situation can result in a violation.



## **EPIRB Installation**

- "Float Free"- means stowed in a manner so that the EPIRB will float free if the vessel sinks.
- Install your EPIRB so that it will not be caught in overhangs, rigging or fishing nets if the vessel sinks.

## **Hydrostatic Release Devices**



 Hydrostatic Release devices must be replaced by the date indicated on the device (usually every two years).



