Three-piece lamp

1 Start this lamp in exactly the same way as the single piece lamp by taking the corners off the blank and then drilling the holes. As you can see, I've already centred the parts of the lamp and am locating the blank onto the hollow live centre

2 If you don't have a bandsaw to take off the corners of the blank, now is a good time to turn them off with the roughing gouge. You don't need to be too fussy with this as the aim is just to make the blank easier to handle

3 Drill through the piece with the auger until just past the halfway point

4 Swap the four-prong drive for the counterbore drive head

5 Mount the blank onto the counterbore drive and drill in from the other side meeting at the halfway point as before. Remember to clear the swarf regularly and use paste wax to lubricate and cool the auger

6 Now that the first blank has been drilled, you can change the drive centre for the boring centre ready for making the mortise

7 Here you can see the boring head at work creating the mortise. Bore in to a depth of 30mm. Hand pressure should be enough to stop the blank from rotating while drilling but if you're at all unsure, bring the toolrest up to the blank as a helping hand

8 The finished mortise is perfectly centred using the locating pin on the boring head. Now swap the boring head back to the driving centre to start the shaping

9 As before, it's helpful to keep a copy of the design beside you as you work. Turn the bottom section. As you can see here, the bottom has a tenon that will fit into the base and the top at the headstock has the mortise we bored in earlier

1

2

3

4

5

6

7

8

9

WT_289_32_37_COLWIN_PRO_CW_MBJRcwS.indd 36 06/01/2016 11:25