17

18

19

20

21

22

23

17 Now we need to fit the top section on to the base section and re-turn the lower portion of the curve. A tight fit alone might allow for this, but to be assured that the top section does not fly off the lathe use the jam chuck you made earlier. I fit a cone head to the revolving centre and locate the cone in the hole on the underside of the jam chuck's tenon. The umbrella is supported on the neoprene face. Do not apply too much pressure from the quill. Using the bowl or spindle gouge re-cut the lower curve until it matches the upper curve. Do not be tempted to follow the cut through to the top

18 In order to help to hide the join, cut a 'V' cut directly in to the join. Now cut matching 'V' cuts 3mm either side of the first 'V' cut. Scorch these black using the Formica. Take special care on the middle one as the material around it is finer than in the solid areas around it. Now abrade the base section to match the stand of the upper section. Seal with cellulose sealer. You can also apply a wax or oil finish

19 Remove the top section from the lathe. Using a 25mm round-nosed scraper cut a round-bottomed hollow in the base. Make it as deep as you feel confident to. It needs to be at least deep enough to take a finger ring, fine necklace, stud earrings or similar. Abrade the interior and seal with cellulose sealer.

20 Mount the jam chuck in to the scroll chuck on its tenon. Using the ring centre again, mount the base of the earring stand between it and the ring centre. The indentation from the first holding assures concentricity. Turn the tenon away using a 10mm spindle gouge. Make the base slightly concave. Abrade and seal the base. The remaining stub can be carved or power sanded away and then finished

21 Take the top section and mount in a similar fashion as previously. The ball finial should fit in the hole of the jam chuck; the umbrella should sit against the neoprene face. The small 2mm stub is your centre reference for a cone centre in the revolving centre. Apply minimal pressure from the tailstock

22 Now, slightly dish the underside of the tenon on the top section. As the top section may be very slightly out of true, measure the lip in the base and mark the depth on the underside face of the top section tenon. From this mark, dish the base towards the centre. Abrade and seal. Remove the stub and seal to a finish. A light coat of finishing oil can be applied all over and then buff to a fine finish

23 Your earring stand is now completed. Fit the two parts together and you should find the grain matches and the scorched 'V' cuts look like a simple decorative feature. If you feel the fit is too tight, you can lightly abrade the edge of the tenon to relieve it a little ●

WT_289_45_49_COATES_PROTECH_AC_bdJRmbacS.indd 49 22/12/2015 10:07