16

17

18

19

20

21

22

23

16 Once the disc has been spun and shaped, give it a light sanding to take out any tool marks. Caution should be taken as the metal has been reduced in thickness and the edge will be sharp. Remove this with abrasive

17 When the cup is finished, drill a 3mm hole down through the centre to take the candle spike. I prefer to use a pillar drill and hold the cup with gloves for safety

18 Polish the cups with a couple of stitched polishing mops, one for applying the polish, which in this case is tripoli abrasive compound designed for copper and brass, and the second one to take the polish off and to buff

19 However, you can go to an even finer compound to make your cup really shine

20 Now to prepare the candle spike, which will be glued into the candlestick. I use a galvanised 50mm nail for this, which I've de-headed with a pair of wire cutters. The nail measures 3mm in diameter and fits through the hole previously drilled in the candle cup

21 Once again, use a pillar drill to make the hole for the spike, ensuring the spike points vertically – again the hole is 3mm

22 Now dry fit all the components together before gluing, with the spike into the candlestick and the cup over the spike

23 To glue the the pieces together use a two-part epoxy resin. I find this one of the strongest glues when working between different materials. Glue the nail into the hole then the cup onto the wooden base

24 Your finished candlestick should look something like this ●

24

WT_290_33_37_CANDLESTICK_CW_bdVSmbCW.indd 37 28/01/2016 14:29