17 Two holes are needed in the side of the barrel to allow attachment to the pillars. Mark a line 7mm in from the back of the main front bead. Bring up the tool rest level with the centre of the barrel and as close as possible. Rotate the barrel so that the grain orientation is horizontal and lock the headstock. Mark this point and then rotate the barrel 180° by using the indexing system and then mark again. In this photo, I've turned the barrel slightly to show the result of this process. Finally, mark the two points with a centre punch

18 This image shows the drilling process, using exactly the same process as for the pillar holes. Mount a Jacobs chuck with a 5mm drill bit in the headstock and let the tailstock point support the barrel. Drill slowly and to a depth of about 10mm. Turn the barrel and drill the other hole in the same way. See step 10 for another way to secure the wood

19 Turn a cove centred on the drilled holes. The profile of the cove needs to match the curve of the pillar that will be attached. Be very careful on the depth of this cove: the next stage will help with this. Fit the two pillars into the base (without glue) and measure the internal distance between the two points where the barrel will be attached. Use vernier callipers for this and transfer this measurement to the diameter at the base of the cove. You can also keep trial fitting the barrel to make sure you've got it right

20 Now reverse the barrel using your chuck jaws or a jam chuck. Once running true, finish turning the back of the barrel, then sand and seal

21 All that remains now is to turn the two supporting pins that will pass through the pillars and into the barrel, using the remaining bubinga blank. The tenon pins should be long enough to pass through the pillars and into the holes of the barrel. Sand, seal and part off these two pins

22 At this point all of the turning is now complete. Loosely assemble all of the components and make sure they fit nicely. Any final adjustments can be done at this stage. Once satisfied, you may want to buff the various components with carnauba wax using a buffing wheel. However, you can use whatever finish you prefer. Once the final finish is applied, glue all parts together. Use a white wood glue sparingly as you don't want any excess to seep out between the joints. Start by gluing the pillars to the base, making sure the holes in the pillars are positioned accurately. Let them dry for a while, before gluing the barrel into place.

23 Once all joints are thoroughly dry, fit the clock insert, stand back and admire your work ●

17

18

19

20

21

22

23



WT_291_14_18_DESK_CLOCK_IW_vsMBiwbdSD.indd 18 02/03/2016 09:29