3

4

3 When happy with the leg, start the copying. Copy turning is simple if you measure everything with callipers and dividers. Start with the overall diameter after roughing: make this to the largest diameter on your first leg. Then approach each part of the design first by diameter then width. The front and back legs do not need to be the same

4 The fit of the tenons must be firm but not tight. Work on a small section first, around 6mm. Measure the drill bit with a set of callipers and cut a 6mm tenon with a parting tool, then check in the seat. Once the fit is right, reset your callipers and finish the tenon to about 30mm

5

6

5 When all legs have been turned, sand them all (remembering not to sand the tenon)

6 Now move onto the centre stretcher. Measure and mark the half way point, then use a set of dividers to start marking outwards both directions. The side stretchers can be plain or shaped. For a smokers bow, the design is a bit more elaborate. Remember you will drill a mortise hole for the centre stretcher at the half way point, so keep that area plain

7

7 The finished legs and stretchers

8

8 Next, drill the various holes for the stretchers using a hinge board. Use two different angles on the front and back legs – 10° for front and 15° for back. They require two different risers in the hinge board. Drill ⅔ through the leg to give a good joint, 200mm from the top of the leg

9 Once drilled, take out the angled risers from the hinge board and drill the side rails at 90°, again to ⅔ deep

10 Now dry fit the chair together. First insert each tenon into each mortice individually, then altogether. Do no glue yet as the top of the seat still needs to be drilled for the arm supports

11 The seat so far. Next time, we complete the chair, having made the back ●

9

10

11

WT_291_27_31_PRO_CW_bdMBvscwSD.indd 31 02/03/2016 09:34