POLARIZED NANO SERIES

SERIES PZN NOMENCLATURE ORDERING GUIDE

Series =	# of Contacts	Wire Length	Termination	Common Options
PZN	04 06 08 10 12 14 16 18 20 22 24 Contact #s less than 10, use "0" first Example: 06, 09, etc	(Skip if not wire term) Length in Inches including tenths example: 12.0 X. 0 = Mixed Lengths	PCB Tail Terminations DD = Straight AA = SMT Horizontal VV = SMT Vertical Wire Terminations WC = Cable* WD = Discrete Leadwire XX = Other* * Consult Factory DD	C=Color Coded Wire COLOR CODED 1 & 11 & 21 = Black 2 & 12 & 22 = Brown 3 & 13 & 23 = Red 4 & 14 & 24 = Orange 5 & 15 = Yellow 6 & 16 = Green 7 & 17 = Blue 8 & 18 = Violet 9 & 19 = Gray 10 & 20 = White BK = All Black BL = All Blue Wh = All White RoHS = RoHS Compliant HTE = High Temp Epoxy
	Examples: PZN-06-DD PZN-08-AA PZN-04-WC		WC	ROHS