ECHO-TWIN PROJECT · INAF

Crack & Detachment Segmentation

User Manual — interface guide, installation instructions, keyboard shortcuts, and application workflow.

This application supports the manual and semi-automated annotation of cracks and material detachments on building facade photographs, turning raw inspection imagery into pixel-accurate, structured training data for automated defect-detection models. Developed within **Work Package 3 of the ECHO-TWIN project at INAF**, it underpins the construction of digital-twin models for structural health monitoring — producing the annotated datasets used to fine-tune deep-learning segmentation models on facade imagery acquired by drone.

Version 1.0.8



- **A*-guided tracing** — assisted, pixel-accurate crack & detachment outlining.
- **SIFT-based projection** — imports and aligns cracks across photos of the same building.
- **Automatic building grouping** — and batch shape-compatibility checks across a group.

macOS | Windows | Linux

Welcome to the guide for the Crack & Detachment Segmentation application. This document covers the user interface (GUI) structure, how to install the software, the main commands, and the general operation of the tool.

1 Interface Overview

The user interface consists of three main sections that allow you to operate in a single desktop window:

Toolbar & Menus

Located at the top. Contains drop-down menus (File, Edit, Tools, etc.) and quick-access buttons for common operations — image navigation, saving, importing. Scrolls horizontally (mouse wheel/trackpad) if the window is too narrow to show every button at once.

Workspace (Canvas)

The central area where the building photograph is displayed, and where you trace the outlines of cracks and detachments.

More Features Sidebar

To the right of the canvas. Clickable buttons for the commands not already on the toolbar (tool selection, view toggles, calibration) — each triggers the action directly, just like a toolbar click. Scrolls vertically if the window is too short to show every button at once.

Status Bar

Located at the bottom, with a scrollbar. Shows real-time console log messages, warnings, and operation status (e.g. successful PNG masks or JSON exports).

2 Installation

Pre-built, self-contained packages are available for macOS, Windows, and Linux — no separate Python installation is required on the target machine. Alternatively, each platform can also be built directly from the source code using the scripts in the `packaging` folder (`build_mac.sh`, `build_linux.sh`, `build_windows.bat`) — see the "Building from source" box under each platform below.

macOS — .dmg

1. Double-click `CrackSegmentation.dmg` in Finder to open it (or, from a terminal, run `open CrackSegmentation.dmg`).
2. A Finder window opens showing the app and a shortcut to the Applications folder. Drag **CrackSegmentation** onto the Applications shortcut.
3. Eject the disk image, then launch the app from Applications or Launchpad as usual.

Do **not** run the .dmg with `./CrackSegmentation.dmg` from a terminal — a .dmg is a disk image, not a script.
On first launch, macOS Gatekeeper may block the app because it isn't signed with a paid Apple Developer certificate. Allow it once via **System Settings › Privacy & Security › "Open Anyway"**, or right-click the app and choose **Open**.

Building from source instead

1. Install Python 3 (the python.org installer already includes Tkinter; with Homebrew, also run `brew install python-tk`).
2. Open Terminal in the extracted source's `packaging` folder.
3. Run `./build_mac.sh` (first time: `chmod +x build_mac.sh`).
4. Result: `packaging/dist/CrackSegmentation.app` and `packaging/dist/CrackSegmentation.dmg`.

Windows — .exe

1. Run `CrackSegmentation-Setup.exe`.
2. Follow the installer wizard (choose an install location, create a Start Menu shortcut).
3. Launch **Crack Segmentation** from the Start Menu once installation completes.

Windows SmartScreen may flag the installer as unrecognized, since it isn't signed with a paid code-signing certificate. This is a standard warning for independently built software, not a sign of a problem — click **More info › Run anyway** to continue.

Building from source instead

1. Install Python 3, checking "Add python.exe to PATH" in the installer (or run `winget install Python.Python.3.12 --source winget`), then close and reopen the terminal.
2. Optional, for a real Setup.exe: install Inno Setup first.
3. Open Command Prompt/PowerShell in the extracted source's `packaging` folder and run `build_windows.bat`.
4. Result: `packaging\dist\CrackSegmentation-Setup.exe` (with Inno Setup) or `packaging\dist\CrackSegmentation\CrackSegmentation.exe` standalone (without it).

Linux .deb

For Debian/Ubuntu-based distributions, install the provided package from a terminal:

```
sudo apt install ./cracksegmentation_1.0.8_amd64.deb
```

Alternatively:

```
sudo dpkg -i ./cracksegmentation_1.0.8_amd64.deb
sudo apt-get install -f
```

After installing, launch the tool by typing `cracksegmentation` in a terminal, or find **Crack Segmentation** in your desktop's Applications menu.

The package is unsigned, so your system may warn about installing software from an unknown source — expected for a locally built package without a GPG-signed repository behind it.

Building from source instead

1. Install Tkinter and venv support: `sudo apt install python3-tk python3-venv`.
2. Open a terminal in the extracted source's `packaging` folder.
3. Run `chmod +x build_linux.sh && ./build_linux.sh` — it builds inside an isolated `.venv` it creates automatically, without touching system Python packages.
4. Result: `packaging/dist/cracksegmentation_<version>_amd64.deb` — install it the same way as above.

3 Tested Configurations

The application has been verified to launch and run correctly on the following real-world machines:

OS	Device	Processor	RAM	Notes
macOS Tahoe	MacBook Pro (MacBookPro17,1)	Apple M1 (8-core: 4P+4E)	8 GB	Model no. MYD92T/A
Windows 11 Home	HP Laptop 15s-fq5xxx	Intel Core i7-1255U @ 1.70 GHz	16 GB	64-bit, x64
Ubuntu 24.04.4 LTS	Victus by HP Gaming Laptop 16-r1xxx	Intel Core i7-14700HX	16 GB	NVIDIA GeForce RTX 4050 Max-Q (AD107M)

4 Main Commands & Keyboard Shortcuts

The software is heavily optimized for quick keyboard use, allowing you to switch between tools without interrupting your workflow.

Action	Shortcut	Description
Crack Tool	`C`	Click the start and then the end of a crack: the route is traced along the edge. `Shift`+click between them adds as many points as needed that the route must pass through (it then follows the thin dark line of the crack and never turns back at a point); `U` removes the last point. With no trace in progress, a click on a crack's end marker deletes the crack; with the cursor on a crack end, the arrow keys nudge it by 1 px.
Detachment Tool	`D`	Click the vertices of a plaster/material detachment: each side follows the outline; `Y` closes the polygon. A click on a detachment's marker deletes it.
Ignore Region	`I` / sidebar	Marks areas where the wall is only partly visible (nets, mesh fences, scaffolding, cables, sparse vegetation). A dialog chooses the shape (rectangle, square, free polygon) and the photo edges it extends to. Rectangle: two clicks on opposite corners; polygon: vertices, then `Y`. With the tool on, drag a corner or side to reshape, click inside to delete. Saved as `-ignore_mask.png` (255 = exclude from training loss and metrics); never imported by `W` / `L`.
Edit Detachment Nodes	`E`	Drag a detachment's clicked vertices; its outline is recomputed live. Press again to leave.

Cut / Join / Link	`1` / `2` / `3`	Two clicks; the same key again leaves the tool. **Cut**: start and end of the part to remove. **Join**: two points on one crack re-route the part between them along another edge, or the ends of two pieces reconnect them. **Link**: two different cracks, clicked at an end or anywhere on the line, become one (a leftover beyond the junction stays a separate crack); JSON and masks are saved at once.
Eraser	Sidebar	Drag the red window over a crack to erase that part (a crack crossed in the middle is split in two); `[` / `]` resize it. JSON and masks are saved on release; `U` undoes.
Remove Uncertain [?]	Sidebar	After a confirmation, deletes every crack on screen marked `[?]`; JSON and masks are saved at once, `U` undoes.
Alternative Route	Sidebar ▶ / `$`	Each press shows another route for the crack traced last, in a new colour; when none is left the arrow turns to ◀ and steps back. `$` makes the route on screen the crack's path; a click on the photo closes the tool.
Retrace Imported Cracks	`V`	Re-traces all imported cracks (A*) onto the real edges of the new photo, discarding implausible results.
Manual Snap / Translate	`T`	Elastic repositioning of an imported crack that hasn't aligned correctly, with automatic snap to the real edge.
Modify Crack Thickness	`A`	Click a crack tract, then `+` / `-` widen or narrow its training mask; `[` `]` widen the left / right side only, `{` `}` narrow it; `Backspace` removes that tract's setting.
Undo / Redo	`U` / `R`	Undoes / redoes the last action: trace, point, deletion, Cut/Join/Link, ignore region, Clear all.
Clear All	`X`	Removes every crack, detachment and ignore region of the photo, also from its JSON; `U` restores them.

Import, Groups & Saving

Action	Shortcut	Description
Save / Save & Next	`S` / `Enter`	Exports JSON and masks; `S` stays on the photo, `Enter` (or `Q`) moves to the next.
Previous / Next Image	Toolbar ◀ / ▶	Moves through the queue without saving.
Import & Align	`W` / `L`	Projects the cracks of another photo of the same building (`W`: the last one saved; `L`: the group photo with the most shapes). When the viewpoints differ a lot, the photo is re-seen in memory from the source viewpoint and matched again; cracks leaving the view are cut at its edge. An unreliable match imports nothing.
Building Portion	`5` / sidebar	Tints **orange** the part of the photo shown by the other photos of the group and pre-sets a window around it; drag inside to move it, drag elsewhere for a new one, click outside to remove it, `5` again when done. `W` / `L` then align on the window and import only inside it.
Assign Building Group	`B`	Type the group number by hand; `Enter` confirms, `Backspace` deletes a digit, `B` cancels.
Check Compatibility (Filter)	`G`	Removes cracks that don't match in shape and path between different photos of the same group (also run after each save).
Validation	Sidebar	Once every photo in `Images` has its JSON: moves the photos fit for training, with JSON and masks, to `Suitable for training`, with a CSV report.
Dataset Split	Sidebar (Mode 2)	Moves the photo to `Training set` (with JSON, masks) or `Test set` / `Validation set` (photo only); asks first if its group is already in a set. Hover: photos per set.
Switch Mode	Sidebar / Menu	Switches between new-images and reload-segmented data sources at any time, without restarting the application.
Scale	`K`	Enters the image scale (cm per pixel) by hand, used for lengths and areas.

View & Navigation

Action	Shortcut	Description
Zoom	`+` `=` / `-` `0` / `0` `Z`	Zoom in / out / reset. Zoom in is no longer on `I` (now Ignore Region).
Pan	`←` `↑` `→` `↓` / wheel	Moves the zoomed view (wheel or two-finger trackpad; Shift = sideways).
Zoom Window	Sidebar	Drag a rectangle to zoom straight onto it (up to 40×); a plain click still traces. Press again to reset the zoom.

Highlight Viewed (HWAV)	Sidebar	Tints green the areas already shown while panning a zoomed photo, with the share inspected; pressed again it starts a new pass.
Crack Report	Sidebar	Click a crack to read its reliability report (length, reliability, confidence, multi-view confirmation, verdict) in the `J` panel.
Show Cracks by Number	Sidebar	Type numbers separated by `;` (e.g. 3;7;12) to show only those cracks; empty = all. Display only: files keep every crack.
Fullscreen / HUD Size	`F` / `H`	Toggles fullscreen; toggles large on-screen text.

Visual Mask Management & Other Keys

While tracing cracks and defects, transparency/overlay visibility can be managed to avoid obscuring the view:

- `N` Shows or hides the blue crack band.
- `Space` Hides the markers (each start marker shows the crack number); `.` hides messages (auto after 15 s).
- `J` Opens/closes the status info panel overlay, with each crack's reliability score (texture along the line) and confidence (0–1, ridge strength against the wall); `[?]` marks an uncertain crack.
- `M` Turns on/off the export of the coloured overlay preview (`-seg` image) at each save.
- `P` Pauses / resumes the session timer.
- `Backspace` / `Delete` Unlocks a "stuck" tool, clearing every operation in progress.
- `?` Shows the on-screen user manual; `Esc` closes the application.

5 Workflow & Application Logic

Session Start

On launch, an initial pop-up lets you choose to work on new images (photos in `Images` without a JSON) or reload processed ones (with a JSON in `JSON files`) for corrections. Photos stay in `Images`; masks go to `Binary files`. This choice isn't final: the **Switch Mode** sidebar button/menu item lets you swap between the two data sources at any later point in the session, without restarting the application. When the last image of the queue has been saved or skipped, a dialog tells you the images are finished (and how many skipped images are still in `Images`) and asks whether to switch to the other mode or exit the application.

Automatic Import and Tracing (A* Retrace)

When a building is covered by multiple frames, the application associates them using SIFT similarity. Cracks traced in one view can be imported into another (`W` / `L`). Since the perspective changes, press `V` to let the A* pathfinding algorithm automatically readjust and "paste" the imported lines onto the physical edges detected in the current photo, discarding gross distortions.

Batch Crack Cleaning and Compatibility

One of the most advanced features is handled by the `compare_and_filter_cracks.py` module (runnable via `G` from within the GUI, or as a standalone script). It scans the exported cracks across photos of the same building; if a crack differs too much from one photo to another — measured by the sinuosity index (how "wavy" the path is relative to a straight line between its endpoints, a metric invariant to the photo's scale/distance) — it is discarded and removed from the final JSONs to keep the data clean.

6 Authors & Credits

This software was developed within the framework of the **ECHO-TWIN** project by the INAF (Istituto Nazionale di Astrofisica) Research Group.

Research Team	
Roberto Spina[1,2]	Code Architecture, Software Design & Lead Development
Fabio Vitello[1]	Project Coordination & Supervision
Eva Sciacca[1]	Project Coordination & Supervision
Leonardo Pelonero[1]	General Support
Salvatore Scavo[1]	General Support

[1] INAF – Catania Astrophysical Observatory [2] Order of Geologists of Sicily (National Register)

AI Disclosure

This application utilizes artificial intelligence models for certain stages of the workflow, specifically for analysis, technical content generation, and development support. The AI components do not replace scientific validation nor do they influence results in a deterministic manner: they are used as assistance tools, not as sources of truth.