DISCONNECT POWER CORD BEFORE SERVICING IMPORTANT - RECONNECT ALL GROUNDING DEVICES

All parts of this appliance capable of conducting electrical current are grounded. If grounding wires, screws, straps, clips, nuts or washers used to complete a path to ground are removed for service, they must be returned to their original position and properly fastened.

ELECTRICAL SPECIFICATIONS

Temperature Control (Position 5)	7- (-11) °F
Defrost Control (w/no door openings)	60 hrs @ 45 min
Thermistor kilo-ohm resistance	
Overtemperature Thermostat	
Defrost Thermistor	70°F


NO LOAD PERFORMANCE


Control Mid-Mid Position


Fresh Food @ 65°F to 90°F Ambient	34 to 40 °F
Frozen Food @ 65°F to 90°F Ambient	3 to 3 °F
Run Time @ 65°F Ambient	30 to 50%
Run Time @ 90°F Ambient	50 to 70%

AIR FLOW









WHEN APPLICABLE DC CIRCUIT SELECTOR CONTROL SWITCH MODULE LIGHT SWITCH SWITCH WHEN USED ORANGE ORANGE ORANGE FZ LIGHT 12 BULBS IN SOME MODELS OVERTEMPERATURE GRAY DUCT BROWN GRAY ORANGE OVERTEMPERATURE THERMOSTAT PINK ORANGE OVERTEMPERATURE THERMOSTAT ORANGE OVERTEMPERATURE


IMPORTANT SAFETY NOTICE

This information is intended for use by individuals possessing adequate backgrounds of electrical, electronic and mechanical experience. Any attempt to repair a major appliance may result in personal injury and property damage. The manufacturer or seller cannot be responsible for the interpretation of this information, nor can it assume any liability in connection with its use.

REFRIGERATION SYSTEM


Compressor	690 BTU/hr
Minimum Compressor Capacity	
Minimum Equalized Pressure	9
@ 70°F	45 to 48 PSIG
@ 90°F	54 to 60 PSIG

REFRIGERANT CHARGE (R134a)



Pub. No. 31-51661 1661X

SXS 25 - 120 V/ 60 Hz 200D5985P019



1661X ND 05K-1466