Jeannie Midi Controller Messages

Ctrl #	Bereich	Controller-Name	Wertebereich
0			
1	0127	Modulation Wheel (MSB)	0127
2			
3			
4			
5			
6			
7			
8			
9			
10	0127	Panorama	0127
11			
12			
13			
14	015	Osc1 Waveform Bank	015 (AP)
15	015	Osc2 Waveform Bank	015 (AP)
16			
17			
18			
19			
20			
21	063	Osc1 Waveform	063
22	063	Osc2 Waveform	063
23	0127	Noise Level/Color	063 Wite noise 64 OFF 65127 Pink noise
24	0127	Osc1+2 Level	0127
25	0127	Osc1+2 Mix	063 Osc1 and increasing Osc2 64127 Osc2 and decreasing Osc1
26	0127	Osc1 PITCH	0127 Pitch -24+24
27	0127	Osc2 PITCH	0127 Pitch -24+24
28	0127	Osc1 Pitch Envelope (P.ENV)	0127 PitchEnv -63+63
29	0127	Osc2 Pitch Envelope (P.ENV)	0127 PitchEnv -63+63
30	0127	Glide	0127
31	0127	Osc2 Detune	0127

Midi Controller Messages

Ctrl #	Bereich	Controller-Name	Wertebereich
32	014	Bank Select LSB	Bank AP
33			
34			
35	0127	Modulation-Slot 3	0127
36	0127	Modulation-Slot 4	0127
37	0127	Modulation-Slot 5	0127
38	0127	Modulation-Slot 6	0127
39	0127	Modulation-Slot 7	0127
40	0127	Modulation-Slot 8	0127
41	0127	Modulation-Slot 9	0127
42	0127	Modulation-Slot 10	0127
43	0127	Modulation-Slot 11	0127
44	0127	Modulation-Slot 12	0127
45	0127	Modulation-Slot 13	0127
46	0127	LFO 1 Shape (SHAPE)	Shape 164
47	1127	LFO 1 Rate (RATE)	0127
48	0127	LFO 1 Amount (AMT) / Mod.Slot 1	0127
49	0127	LFO 2 Shape (SHAPE)	Shape 164
50	1127	LFO 2 Rate (RATE)	0127
51	0127	LFO 2 Amount (AMT) / Mod.Slot 2	0127
52	0127	LFO 3 Shape (SHAPE)	Shape 164
53	1127	LFO 3 Rate (RATE)	0127
54	0127	LFO 3 Amount (AMT)	0127
55	0127	Modulation-Slot 14	0127
56	0127	Modulation-Slot 15	0127
57	0127	Modulation-Slot 16	0127
58	0127	Modulation-Slot 17	0127
59	0127	Modulation-Slot 18	0127
60	0127	Modulation-Slot 19	0127
61	0127	Modulation-Slot 20	0127
62	0127	HP Filter Cutoff (FRQ)	OFF / 202000Hz
63	0127	HP Filter Resonanz (RES)	0127

Midi Controller Messages

Ctrl #	Bereich	Controller-Name	Wertebereich
64	0127	Sustain	OFF 063 ON 64127
65	0127	Modulation-Slot 21	0127
66	0127	Modulation-Slot 22	0127
67	0127	Modulation-Slot 23	0127
68	0127	Modulation-Slot 24	0127
69	0127	Modulation-Slot 25	0127
70	0127	Modulation-Slot 26	0127
71	0127	Modulation-Slot 27	0127
72	0127	Modulation-Slot 28	0127
73	0127	Modulation-Slot 29	0127
74	0127	SVF/Ladder Filter Cutoff (FRQ)	2020KHz
75	0127	SVF/Ladder Filter Resonanz (RES)	0127
76	0127	VCF Envelope 1 Attack (ATK)	011.9sec
77	0127	VCF Envelope 1 Decay (DCY)	011.9sec
78	0127	VCF Envelope 1 Sustain (SUS)	0127
79	0127	VCF Envelope 1 Release (REL)	011.9sec
80	0127	AMP Envelope 2 Attack (ATK)	011.9sec
81	0127	AMP Envelope 2 Decay (DCY)	011.9sec
82	0127	AMP Envelope 2 Sustain (SUS)	0127
83	0127	AMP Envelope 2 Release (REL)	011.9sec
84	0127	State Variable Filtertyp (TYP) Ladder Drive (DRV)	040 TP 40124 HP 124127 BP 0127 DRV
85	0127	Osc1 PWAMT/SPREAD/PRM_A	0127
86	0127	Osc2 PWAMT/SPREAD/PRM_A	0127
87	0127	Osc1 PWMOD/SAWMIX/PRM_B	03 Pulsweite 45 Envelope 6121 Mod Amount 0127 SAWMIX 0127 PRM_B
88	0127	Osc2 PWMOD/SAWMIX/PRM_B	03 Pulsweite 45 Envelope 6121 Mod Amount 0127 SAWMIX 0127 PRM_B
89	0127	SVF/Ladder Filter Keytrack (KEY)	0127
90	0127	Filter Envelope (ENV)	0127
91	0127	Modulation-Slot 30	0127
92	0127	Modulation-Slot 31	0127
93	0127	Modulation-Slot 32	0127
94	0127	Modulation-Slot 33	0127
95	0127	Modulation-Slot 34	0127

Midi Controller Messages

Ctrl #	Bereich	Controller-Name	Wertebereich
96	0127	Modulation-Slot 35	0127
97	0127	Modulation-Slot 36	0127
98			
99			
100			
101			
102	0127	Wave Envelope Attack	0127
103	0127	Wave Envelope Decay	0127
104	0127	Wave Envelope Sustain	0127
105	0127	Wave Envelope Release	0127
106	0,15,0	WaveShaper Gain	0127
107	013	WaveShaper	0127
108	0127	Fx Parameter (P1)	0127
109	0127	Fx Parameter (P2)	0127
110	0127	Fx Parameter (P3)	0127
111	0127	Fx Clock Frequency (CLK) 1060KHz	0127
112	0127	Fx - Mix	0127
113	015	Fx - Program	0 = off 115 Fx Program
114	0127	Filter Switch StateVariabel/Ladder	063 SVF 64127 Ladder
115			
116			
117			
118			
119			
120			
121			
122			
123			
124			
125			
126			
127			