




CAMERA



HEAD_PANEL
THD0515-45CL-SN

Pin	Function	Pin	Function
47	L_SPK_P	45	
	44	44	L_SPK_N
	43	43	
	42	42	
	41	41	GND
	40	40	R_SPK_P
	39	39	
	38	38	R_SPK_N
	37	37	
	36	36	
	35	35	GND
	34	34	LINPUT1
	33	33	
	32	32	RINPUT1
	31	31	
	30	30	TOF_ENL
	29	29	SDA6
	28	28	SCL6
	27	27	
	26	26	GND
	25	25	SCL0
	24	24	RESET
	23	23	TOUCH_R
	22	22	TOUCH_L
	21	21	LCD_PWM
	20	20	SPI0_CE1
	19	19	SPI0_CE0
	18	18	LCD_DC
	17	17	
	16	16	GND
	15	15	SPI0_MOSI
	14	14	
	13	13	GND
	12	12	SPI0_CLK
	11	11	CAM_D0N
	10	10	CAM_D0P
	9	9	
	8	8	GND
	7	7	CAM_D1N
	6	6	CAM_D1P
	5	5	
	4	4	GND
	3	3	CAM_CN
	2	2	CAM_CP
	1	1	CAM_GPIO
46		2	+3.3V
		1	-2.3V