MANUAL

How it works

Porcelain

Porcelain is much more hygienic and easier to keep clean than other materials such as plastic or similar. And of course – it lasts much longer.

Urine hose

A urine hose is mounted below the urine bowl. Urine separation makes the faeces dry, and provides a odorless experience. Water flush is possible in the urine bowl.

Drop pipe 200 mm

Black 200 mm (OD) drop pipe of polye-thylene. The surface of the pipe is smooth, that dirt does not stick to. Long length means that the waste is not visible.


Urinary Drain 50mm(OD)

Urine drainage from the floor down to the urine receptacle.

Urine Container

The urine is collected easily in a can. Mix 25% urine and 75% water for use as plant nutrients.

Note, please read the instructions before ordering or starting installation.



Water connection

If water supply is possible, use R15 1/2".

Ventilation

Evacuates odors and airborne bacteria above the roof.

Fan

A fan is mounted on the lid. Makes the waste dried out, easy and smooth.

Dry waste

EcoDry "BOX" of 100 liters placed under the floor, where solids and paper ports. After 3 months the waste is dry, odorless and weighs only 10-20 kilos. The content is then transferred to a compost latrine for composting. The box is emptied about 1-2 times per year. A big plastic bag is suitable to put in the BOX to collect the waste.



Details:

Water supply: Flexible stainless steel hose.

1/2", R15

Water flush: Water flush possible in the

urine bowl.

Power water flush: 9V battery (lasts about a

season). Solenoid flushes as long as the button is pressed. Battery eliminator can be selected as

options.

Dimensions: Height 450 mm, width 395 mm,

depth 580 mm (note the new higher standard = 450 mm)

Urine outlet: 50 mm OI

Assembly: Toilet is glued to the floor using

wetroom silicone. Toilet is stable and should not be screwed.

Drop shaft: 200 mm (diameter). Black polyet

hylen. (is not included when


purchasing only toilet).


Toilet Seat: Standard white plastic seat

included.



Example installation WC





1. Find exact location


- Check that the holes don't hits heating coils, etc.
- Does the waste barrel fits be neath the floor? How deep down does it need to be?

2. Mark and cut holes

- · Mark holes as described above.
- · Cut up the holes

3. Mount the drop pipe


- Adjust the length of the 200mm pipe. Should stick up about 170 mm above the floor. Let it stand down as far as the collection barrel requires. (so that the "box"/device can be pulled out, without the pipe gets stuck in the bottom part.
- Fix the pipe to the floor with angles. (Note, the 200 mm pipe can not be glued.)
- Seal the gap between the floor and drop pipe with silicone.



4. Install urine drains


- 50 mm OD PP pipes, through the floor and proceed to the urine receptacle.
- Slide the white sleeve adapter down to the floor and seal it with silicone.
- Some brands of 50 mm pipe, has a high edge. In that case

 cut edge with a knife so plastic bus tion may come down enough (Located on the urine tube).



5. Stick down the urine hose


- Cut the urine hose to about 30 cm. (Must be too long and knit into the 50 mm pipe.)
- Rest chair on the side, so that urinary hose going to stop in.
- · Insert the hose
- Push the white plastic bushing on the urine hose down (50mm). Should seated properly.



6. Place and glue toilet

- Put down the toilet so it fits the 200 mm pipe.
- Place a string of silicone around the toilet. Even with a damp finger.








7. Mount the seal strip

- Put the seal strip (included) between the drop shaft and the porcelain.
- Seals and making the ventila tion working properly, and prevents bacteria and odors co ming up to the toilet.

8. Water supply – if possible

- Install a ballofix on the wall 20 cm above the floor.
- Screw on EcoDrys water contion R15.
- If water connection dosn't exists, rinse urine bowl manually with a little water.

Other oppurtunities with EcoDry




Fits many collection devices!

EcoDry toilet can be used for many different collection units or your own solutions. Switching to EcoDry porcelain toilet is an easy way to get a higher standard!



Collection units



EcoDry Box

The most comfortable option. Only the toilet is visible in the toilet area. High capacity and easy management. Fan included, which makes the waste completely dry. The whole processing is done outdoors, or under floor.

Assembly:

Follow the section "Mounting toilet". Should be about 70 cm between the joists to the surface The box is on. Good space around the box to provide urine receptacle on. The length of the drop shaft protrude 17 cm above the floor, and should not stick longer inside the box than to Boxlådan can be easily "pulled out" to empty. Connect the fan vent. hose to pipe up over the roof. Make holes in urinkär- let, and connect the drain urine / urine tube.

Material: Polyethylene **Capacity:** 100 liters

Drain: approx 1 time / season

Time until the waste is dry: approx 3 months **What's included:** toilet seat, toilet lid, solid waste containers (Box with lid), nedfallssrör 75cm, fan (Mounted), flexible vent.slang 1m.

What is needed: any extension of urinary drainage, ventilation, receptacle for urine,

possibly ballofix.



EcoDry Low Container

Compact solution that is lowered to the floor. Suitable when the space under the floor is limited. The toilet is mounted on the metal top of the container. Emptying is done by folding up the toilets forward.

Assembly:

Read also instructions on page 2. Comes with toilet glued to the top of the container. Cut a hole in a square 530 x 320 mm. Lower down the drain / toilet in the hole and connect to the ventilation and urine containers.

Material: Stainless **Kapacitet:** 28 liters **Dump:** quarterly

Time until the waste is dry: approx 3 months **What's included:** toilet seat, toilet lid, solid waste containers, fan (mounted), drop shaft (mounted), flexible vent. Hose 1 m.

What is needed: urinary drainage, ventilation, receptacle for urine, possibly ballofix.

Owners manual:

Care:

- Drain fecal material

Emptying the box/containers waste in a latrine compost. The longer the waste may be in the Box/Container the drier and easier the waste becomes. 3 months is appropriate. Use large plastic bag/trash bag.

- Emptying the urine container

The urine container (depending on size) is probably emptyed more frequently. Keep track of this time. Then use the urine as well fertilizer by mixing 75% water, 25% urine.

- For winter

If you do not use the toilet in the winter, turn off the water and drain all the water. Empty by flushing once after the water turned off. Tighten loose the flexi hose from the ballofix, otherwise the solenoid valve can freeze.

- Flush the urine drains in toilet - seat

If you do not have the water flush installed, flush the toilet manually with a cup of water.

Spare parts:

- Solenoid
- · Flush equipment

