

			1						
ADAPTER	SOCKET	Vcc, AVcc	GND	RST	SCK	MISO	MOSI	XTAL1	SUPPORTED CHIPS
ATTINY_A1	DIP-28	7,20	8,22	1	19	18	17	9	ATtiny48/88/168/328/
	DIP-20	20	10	1	19	18	17	5	ATtiny2313/4313,
	DIP-20	5,15	6,16	10	3	2	1	7	ATtiny26/261/461/861
	DIP-14	1	14	4	9	8	7	2	Attiny24/44/84
	DIP-8	8	4	1	7	6	5	2	ATtiny12/13/15/25/45/85,AT90S2323
ATMEGA_A1	DIP-40	10,30	11,31	9	8	7	6	13	ATmega16/32/164/324/8535/
	DIP-40	40	20	9	8	7	6	19	ATmega162/8515, AT90S8515
	DIP-28	7,20	8,22	1	19	18	17	9	ATmega8/48/88/168/328
TQFP32_A1	SMD	4,6,18	3,5,21	29	17	16	15	7	ATmega8/48/88/168
TQFP32_B1	SMD	4,31,32	3,28	24	15	17	16	1	ATmega8U2/16U2/32U2
TQFP44_A1	SMD	5,17,27,38	6,18,28,39	4	3	2	1	8	ATmega16/32
TQFP44_B2	SMD	38	16,17	4	3	2	1	15	ATmega8515,AT90S8515,AT89S51/.
TQFP64_A1	SMD	21,52,64	22,53,63	20	11	13	12	24	AT90USB64/128
TQFP64_B1	SMD	21,52,64	22,53,63	20	11	3	2	24	ATmega64/128
AT89S_A2	DIP-40	40	20	9	8	7	6	19	AT89S51/52/53/8253/8252
	PLCC-44	44	22	10	9	8	7	21	AT89S51/52/53/8253/8252
	DIP-28	20	10	1	19	18	17	5	AT89S2051/4051