## Adapter DIP-40\_A1

EzoFlash+ adapter for MCS-51 microcontrollers in DIP-40 package.

## 1. Part list.

R1, R2 - 1k2

R3 - 2k2

R-PACK - 9x10k or 8x4k7...10k

C1, C2 - 24pF


X1 – Quartz resonator 4.43 MHz (4...10MHz)


BU5 – Straight pin-header 2x16, division 2.54


BU7 – Straight pin-header 1x5, division 2.54

BU8 – IC Socket DIL-40


## 2. Schematic, PCB and pictures











## 3. Settings, verified chip list and info.

Willem programmer software version 0.97ja

Selected device group MCS-51 > AT89C5x > ... Vcc=5.0V, Vpp=12.0V. Jumpers Jp1, Jp3 (5.0V), Jp5 (A18) Verified chips AT89C51, AT89C52, AT89C55, Intel D87C51FC, AT89C51RC.

Chips AT89C51RC and AT89C55WD with activ lockbits can't be erased, Vcc=6.2V required. Software doesn't support chip AT89C51RD.

Test results find in chip\_test.xls file Report problems and share your experience on Willem and EZoFlash forums.