

Translated to: English

Show original

Options ▼



midi

MIDI controller


MIDI Controller Instructions



After turning on the VIA-C and connecting the keyboard, if the model number on the upper right corner is "Model + MIDI", it supports this function. If it is "Model + DIAL", it does not support this function. You need to flash in the firmware that supports MIDI.



Some models of keyboards have added a MIDI controller function, which can simulate the knob as a MIDI CC controller and output the value of CC 0-127



- 1.将所需的CC值同时设置到旋钮的顺时针和逆时针键位,转动旋钮,即可输出MIDI信号。
- 1
 - 2.CC值设置到旋钮顺时针键位,输出数值自增,设置到逆时针键位,输出值自减

Application of MIDI in Lightroom



After setting the MIDI key value on the knob, with MIDI2LR, the knob can be used for Lightroom color correction



MIDI2LR version 5.xxx only supports Lightroom 11 Classic or later MIDI2LR version 4.xxx only supports Lightroom 10 Classic

Mac OS side installation tutorial

- │ │ 1.根据当前使用的Lightroom来选择对应版本的MIDI2LR下载
 - Mac OS MIDI2LR 5.x下载链接: https://cxt-studio.lanzouf.com/iVFc602c2z0h
 - Mac OS MIDI2LR 4.x下载链接: https://cxt-studio.lanzouf.com/iF7rS02c3ufi
- 5 2.将MIDI2LR-x.x.x.x-osx-installer.dmg下载到任意一个能找到的目录
 - 3. 如果此时您正在使用Lightroom,那么现在请关闭,然后打开刚才下载的dmg文件,双击打开
 - 4.打开后弹出新的界面,双击弹出的界面中的MIDI2LR图标,开始安装
- 9 10 11

2

3

6 7

8

5.随后一路确认即可,默认路径通常适合大部分用户

https://cxtkb.com/zh/midi

Google

14

Translated to: English

Show original

Options ▼

15 7.安装完成后可打开Lightroom测试,此时MIDI2LR应该会随着Lightroom启动,此时即安装成功

16 17

8、若启动Lightroom后MIDI2LR未启动,且在文件-增效工具中显示该插件不可用,那么通常是版本错误

18 19

9.在Mac OS Mojave或更高版本中,第一次使用MIDI2LR的时候,可能会出现辅助功能授权提示

20 21

10.进入系统偏好设置-安全性与隐私-隐私-辅助功能,在右侧勾选MIDI2LR即可

Windows side installation tutorial

1.根据当前使用的Lightroom来选择对应版本的MIDI2LR下载
Windows MIDI2LR 5.x下载链接: https://cxt-studio.lanzouf.com/iwKf802c2z3a
Windows MIDI2LR 4.x下载链接: https://cxt-studio.lanzouf.com/izD8902c3udg

2.将MIDI2LR-x.x.x.x-windows-installer.exe下载到任意一个能找到的目录

7 3.如果此时您正在使用Lightroom,那么现在请关闭,然后打开刚才下载的exe文件,双击打开并安装即可

4.Windows端无需做特殊设置,安装完即可使用

Brief tutorial

8

2

1.先前往VIA-C中,将旋钮设置为MIDI CC值,需注意,键值需要成对设置,顺时针和逆时针需要设置同一个CC值,顺时针表示增加,逆时针表示减少,如果只设

2.打开Lightroom,等待MIDI2LR界面弹出后,转动旋钮,此时MIDI2LR界面中会出现新的一行



1 │ 左侧的MIDI命令就是刚才为旋钮设置的CC值,右侧是对应的LR命令,点击可从弹出的列表中选择所需要的值,设置完成后回到Lightroom,转动旋钮即可生效

3 │ 若是使用过程中重新插拔键盘,或者修改了CC值,MIDI2LR可能会没有反应,此时进入Lightroom-文件-增效工具额外信息-MIDI2LR-关闭应用程序然后再按此

© 2022 CXT Labs. all rights reserved. | Provider CXT

https://cxtkb.com/zh/midi 2/2