Translated to: English

Show original

Options ▼



specialkeycode

Special key description

special key

Included in the special keys of the key-value category 系统应用键 , which are not valid for all systems, move the mouse to the corresponding key value, and a prompt will appear at the bottom of the interface



- ► F13-F24 is not supported by default in Windows, and Windows does not assign functions to it. If you want to use F13-F24 as a shortcut key for a certain software, you must support it by the software itself.
 - For example: F13-F22 can be captured when the shortcut keys of WeChat are set, but F13-F24 cannot be captured when the shortcut keys of Netease Cloud Music are set

customize

The key is provided in the basic key 自定义. The key value is a temporary key value. It is mainly used to cooperate with CXT_KBT before the official version is released. Set the same layer and the same key as other functions, you can use

D6U7

- ► Since the CXT keyboard itself does not support setting the key value separately for the key press and release, but because some users have this demand, the additional key value is added
- ► When the key value is set to a layer other than 6 or 7, press the key to trigger the key value of the key in layer6, and release it to trigger the key value of the key in layer7

∇ key

- Penetration key: In the default configuration of the keyboard, except for layer0, the default key values of the keys of all other layers are penetrating keys
- ► The keyboard itself has multiple layers . See here . This key value indicates that the current key position is in the current layer, and the key value is the same as the previous layer. If the previous layer is also the key value, it will continue to penetrate until layer 0.
- For example: when the first row of layer0 is set to 1, 2, 3, 4, and the first row of layer1-7 is all penetrating keys, then no matter which layer is switched to, it will trigger 1, 2, 3 defined in layer0, 4.

TH45

Long and short press the combination key, short press will trigger the value set in layer 4 of the current key position, and long press will trigger the value set in layer 5 of the current key position

TH67

Long and short press the combination key, short press will trigger the value of the current key set in layer 6, and long press will trigger the value of the current key set in layer 7

Burst key 1

▶ Burst key, mode 1: When pressed, the value of the current key set in layer 7 is continuously sent, and when released, it stops sending.

Burst key 2

Burst key, mode 2: Continuously send the value of the current key set in layer 7 when pressed, it will not stop when it is released, and stop until the next time it is
pressed.

https://cxtkb.com/zh/specialkeycode



Translated to: English

Show original

Options ▼

• Burst key, mode 3: short press and release triggers the value set in layer 7 of the current key position, and continuously sends the value set in layer 7 of the current key position when long press is released, until the next time the key is pressed to stop sending



Long press and short press time threshold is 200 milliseconds, press and release within 200 milliseconds, it is judged as short press, press and release after 200 milliseconds, judge as long press

© 2022 CXT Labs. all rights reserved. | Provider CXT

https://cxtkb.com/zh/specialkeycode