# Populife Smart Keybox

—— User Guide ———


, s	1	2	3
	4	5	6
	7	8	9
		0	

populife.co


# **Components Overview**



Populife Smart Keybox x 1



Rubber mat x 1



Self-tapping screws x 4



Expansion screws x 4





Nylon rubber stopper x 2



Screwdriver x 1

# **Specifications**

Model K1

**Dimensions** 195(H) x 66(W) x 42(T) mm

Inner space of shackle 60(W) x 35(T) mm

Material Zinc Alloy, Steel, Plastic,

Silicon Rubber

Weight 1.2 kg
Wireless Protocol BLE 4.1


Batteries 4 x AAA (Not included)
Unlock Mechanism Bluetooth, PIN code

Water and Dust Proof IP 66

**Drop Test** 

**Working Temperature** -40 °F (-40 °C) ~ 131 °F (55 °C)


1 meter



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

# Installation


## Mount it on a surface if needed




# Installation


## Side view


# To hang on a doorknob






# **Buckle usage**











# **Battery Installation**



# **Identification**



# **Quick Start Guide**

### Factory mode (Working without App)

- 1. Open the battery cover with the provided screwdriver and insert 4 AAA lithium batteries as described in page 5.
- 2. Touch the keypad to wake up the Keybox, enter the default password 1234 and end with " a ". You will hear a long beep sound suggesting the Keybox is activated.

#### Note

- 1. The batteries are not included in package, you need to prepare them by yourself.
- 2. The " a " button is not part of the password, it's for confirmation.

#### Read these notes before using

- 1. In "Factory mode" (Before App pairing), the default keypad password is 1234. Once the lock is paired in Populife App, the default password becomes invalid and you will get a new Admin password in "Lock settings" in App. If you delete the lock from the App, the password 1234 becomes valid again.
- 2. Every time the Keybox is closed, it will automatically lock itself.
- 3. To control the Keybox more conveniently, like unlocking via Bluetooth, creating and sharing passwords, you can install "Populife" App through App Store, Google Play or the QR code below.
- 4. The Keybox is controlled by the phone via Bluetooth. While operating, please enable phone Bluetooth, and make sure that the Keybox is within the range of phone Bluetooth(Allowing for different circumstances, the suggested distance is less than 2 meters);



App Store



Google Play

## How to Use

### Pair the Keybox in App

In the homepage of Popuife App, click "+" on top right > Select "Keybox" > Select the option with "+" > Follow the instructions to complete the pairing.

If the pairing is unsuccessful, you can take the following steps:

- · Restart Bluetooth and Internet connection on your phone;
- · Restart Populife App on your phone;
- · Pair the Keybox again.

If it still doesn't work, maybe because the lock has been paired before. To make it, you can do either of the following:

- 1. If the lock was paired before, please get the previous owner of the lock to delete it in the App. The "Delete" button can be found at the bottom of "Lock settings".
- 2. If the lock is newly bought, you can long-press the RESET button until a beep sound which indicates the Keybox has been reset. The RESET button is under battery cover shown in page 5.

## **Unlock by Admin Password**

Admin password is generated after pairing successfully, which can be used to unlock via keypad. If the number you entered is incorrect, you can press the "  $\upbeta$  " key to re-enter. Or you can enter the Decoy Code to unlock it. For details about decoy code, please refer to page 10 of this manual.

#### Note

1. If you want to modify it, you can follow below:

Lock page in Populife App > Settings > Admin Password > Enter your password > Save

2. If you enter the wrong password continuously for more than 5 times, the keypad will be disabled for 5 minutes. You can enable it immediately by unlocking via Bluetooth in Populife App or wait for 5 minutes to enter the correct password again.

## Unlock by Bluetooth key

Turn on Bluetooth, make sure the phone is close to the Keybox, and unlock the Keybox by clicking the UNLOCK button in App.

## How to Use

### **Sharing Password**

It is a 6-9 digits, time-limited password which can be created in App by the administrator or authorized user. You can create and share passwords by following these steps: Lock page in Populife App > Passwords > Click the button  $\equiv$  on top right > Create password > Configure and create the password > Share

#### Note

- One-time password is valid within 6 hours after created;
   Permanent/Clear/Cyclic password must be activated within 24 hours after created;
   Period password must be activated within 24 hours from its Start time:
- When creating a Customized password, ensure that the phone Bluetooth is enabled and your phone is close to the Keybox.

## **Sharing Bluetooth key**

Lock owner can authorize other Populife's REGISTERED users to unlock via Bluetooth keys in App. You can share Bluetooth keys by following these steps:

Lock page in Populife App > Bluetooth keys > Click the button " = " on top right > Send Bluetooth key > Configure and set the Bluetooth key > Send

### Unlocking records

You can view the operation records of the Keybox. And the operation will be recorded only when the Keybox is unlocked successfully. You can view and synchronize the records by following these steps:

Lock page in Populife App > Settings > Records

You can synchronize the unlocking records via Bluetooth near the Keybox.

# Security

#### **Automatic locking**

If the Keybox is unlocked but remains closed, it will automatically lock itself in 30 seconds.

#### **Security Alarm**

If the Keybox is not closed properly, it will beep to indicate that it is not secure.

#### **Decoy Code**

You can enter up to 10 digits before or after the correct password to prevent someone from peeking your password.

For example, you can unlock it by entering 123159<u>876544</u>3345, where <u>876544</u> is the correct password.

The maximum length for one attempt is 16 digits. This feature is enabled after pairing in App.

## **Emergency Jump Start**

The batteries can support up to 10,000 operations of unlocking/locking (approx. 12 months).

If the batteries power is drained, an external 9 Volt battery can be used to provide emergency power.

The 2 pins of the battery must be aligned with the 2 pins at the bottom of the Keybox as shown below.



# PDPULIFE

Instagram: www.instagram.com/populifelock

Facebook : www.facebook.com/populife

**E-mail** : support@populife.co

www.populife.co