

## Connecting to the BBB over SSH and Opening Virtual Window

1. Open PuTTy.exe


2.




3. Enter the IP address of BBB, (192.168.7.2) in Host Name




- 4. Keep Port number as 22
- 5. Now, click on SSH Option in bottom left corner




6. Click on X11 and Check the Box Enable X11 Forwarding



- 7. Now, Click on Session at the TOP LEFT Corner
- 8. Give this configuration any name, like in this case, BBB and Click SAVE



- 9. Double click on your saved configuration name, BBB
- 10. You will see a window opening and Security Breach Alert.
- 11. Press Yes and continue.
- 12. Now, login as root, no password is set for default or, it would be 'temppwd'.
- 13. Refer the Internet over USB manual.
- 14. After connecting to the internet over USB, press the following commands: sudo apt-get update sudo apt-get install x11vnc
- 15. Open Xming on your laptop
- 16. Write the following command in PuTTY: **startlxde**
- 17. You will see a GUI opening.



-Sonal

This Is the OS of your BBB being accessed through a virtual GUI application named Xming.