U74 80286
U76 80287
VLSI_TOPCAT_VL82C320
VLSI_VL82C331
SIMM_72PIN
8 BIT MODE
BIOS ROM
8 BIT MODE
OPTION ROM
U126 8042
EPM7256S-208
TOPCAT_IO_DECODER_REV2_EXP2
FLOPPY DRIVE CONNECTOR
PRIMARY_IDE
ISA_16bit_Slot
ISA_16bit_Slot_A1
TODO(QUARTUS): ONLY PASS IOCH_RDY FROM PICO
WHEN BUSOE IS ACTIVATED
IOCH_RDY FROM PICO IS INVERTED
SO INVERT AGAIN
PicoGUS created by polpo on GitHub:
https://github.com/polpo/picogus
OPEN DRAIN FROM CPLD
USB DEVICE ONLY
PICOGUS PROGRAM
DIRECTLY ON RP2040
ONLY
J31 USB_PICOGUS
J32 USB_RP
J9 MIDI_OUT
GP9 –
GP14
JUMPERS
TO GND
RESET
TO GND
Created by LimeProgramming (Adam)
https://github.com/LimeProgramming/USB-serial-mouse-adapter
J18
FLOPPY DRIVE CONNECTOR
U95 PICO_RP2040
U96 PICO_RP2040
CONDITIONAL ON
WHEN PICOGUS ACTIVE
ALWAYS ON
PCM5100
AUDIO
CHECK SOIC
PACKAGE SIZE!
NB: CAPACITORS LABELED CAP
ARE TO BE DETERMINED LATER
AND NOT POPULATED BY DEFAULT
R214 4k7 FIRST
TEST WITHOUT
OPEN (PULLED HIGH): 286
CLOSED (LOW): 386SX
CHMOS KBC
LEAVE OUT
R10
TERM AND
LOAD CAP
TO BE TESTED
LOAD
POSSIBLY
15pF
FUSE 8A
FUSE 5A
STANDBY
POWER
LED
POWER
SWITCH
RESET
SWITCH
PIN1: VBAT=6V